




ASSEMELING INSTRUCTION


Ax1	Bx1	Cx1	Dx4 (M6x45mm)
			
			Ex1
			

1.



1.Filp the part (B) and install it on top of (A).

2.



Note :
The Plate on the part (C) can rotate .
Please align it with the screw holes during installation!

3.

