
ASSEMBLY INSTRUCTION

3-Tier Bookshelf


Item NO.: FBS020301、FBS020302、
FBS020303、FBS020304






Version：F021825

Part Identification

While not all parts are labeled, some of the parts will have a label to help distinguish similar parts from each other. Use this part identification to help identify similar parts.






①	②	③
 Metal Frame 2 pcs	 Crossbar 2 pcs	 Shelf 3 pcs

A	B	C1	D	E1	F1
 M6*25 mm 12 pcs	 M6*12 mm 4 pcs	 Plastic Anchor Ø8*35 mm 2 pcs	 Leveler 4 pcs	 M6*20 mm 1 pc	 Allen Key 1 pc
		C2  Ø4.5*45 mm 2 pcs		E2  1 pc	F2  Wrench 1 pc

Step 01

NOTE: DO NOT fully tighten all bolts at this step.
Product support email: andy@foluban.com


Lay the Metal Frames(①) Parallel to each other on a clean smooth surface such as carpet or cardboard. Fasten 2 Crossbars(②) with Bolt(E1) and Nut(E2) by Wrench(F2) and Allen Key(F1). Secure the Crossbars(②) on the frames with Screws(B). Do not tighten fully.



Step 02

NOTE: If holes don't align, loosen all bolts and adjust the holes slightly. After all holes are aligned, fully tighten all bolts.


Attach 3 Shelves(③) into the assembled metal frames(①) with Screws(A) by Allen key(F1). Do not fully tighten all bolts until all parts are in place. Adjust levelers (D) as needed for uneven flooring.



Step 03

Product support email: andy@foluban.com

To prevent injury and property damage from unexpected tipping of furniture, we highly recommend installation of the anti-tip kit included with this product. Drill holes at marked spot with a drill bit. Carefully hammer in the Plastic Anchors(C1). Attached the frames into the hole using Wall Screws(C2).




Thank you for purchasing FOLUBAN Bookshelf. If any part is missing or damaged, please do not hesitate to contact us, we will send you the replacement immediately.


Email: andy@foluban.com

ASSEMBLY TIPS

1. Please read the assembly instructions first and become familiar with the parts.
2. Proper assembly of this item requires 2 people.



3. Unpack and assemble this unit in an spacious area, assemble the unit on top of the empty carton or carpet to prevent scratches.



4. To avoid accidentally discarding small parts or hardware, DO NOT dispose of any contents until assembly is completed.
5. **Do not fully tighten all bolts until all parts are in place.** Failure to follow these instructions may cause the bolts to misalign during assembly.

CARE INSTRUCTIONS

(1) Hardware may loosen overtime. Periodically check that all connections are tight.

(2) Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

(3) All hot serving dishes should be placed on a pad.

(4) Any liquid spilled onto the furniture should be cleaned up immediately with a dry cloth.