



Product Usage Instructions





NO JUMPING.







INSTALLATION GUIDE

Suggest using electric tools for installation


SKU:16008I




SKU:16012I




SKU:16013I




SKU:16014I




SKU:16020I




SKU:16021I




SKU:16022I







SKU:16023I




The Red Mark on component J represents the bottom surface




STEP 21





When opening or closing,
it is recommended to use both hands
to simultaneously push and pull






When you feel that the door latch is too tight and inconvenient to use, you can use a screwdriver to adjust it to the appropriate position




5	 #7 x 3.5x14	40 PCS	18	 80*80*2.5	4 PCS
19	 M6*12	16 PCS	14		1 PCS


STEP 19















There is an upward arrow label attached to the door panel



5	 #7-ϕ3.5X14	4 PCS	16		2 PCS

STEP 20



①	 KD Cam	44 PCS	⑪		1 PCS
②		44 PCS	⑫		14 PCS
③	 #8-Ø4X30	30 PCS	⑬	 #8-Ø4X20	8 PCS
④	 8 x 30MM	38 PCS	⑭		1 PCS
⑤	 #7-φ3.5X14	86 PCS	⑮		2 PCS
⑥	 Accessor ies 6-7, sepaate during installation	2 PCS	⑯		2 PCS
⑦	 Accessor ies 6-7, sepaate during installation	2 PCS	⑰	 L=428mm	1 PCS
⑧	 M4 X 30mm	2 PCS	⑱	 80*80*2.5	6 PCS
⑨	 M4 X 25mm	2 PCS	⑲	 M6*12	24 PCS
⑩		4 PCS			


installation procedure

2		36 PCS	15		2 PCS
5	 #7-ø3.5X14	8 PCS	6		2 PCS


STEP 1



Suggest using electric tools for installation





STEP 18




8	 M4 X 30mm	2 PCS	10		2 PCS

STEP 15




13	 #8-Ø4X20	8 PCS			


STEP 16




9	 M4 X25mm	2 PCS	10		2 PCS


STEP 17



①	 KD Cam	4 PCS	④	 8 x 30MM	2 PCS


STEP 2







①	 KD Cam	8 PCS	④	 8 x 30MM	12 PCS


STEP 3









③	 #8-Ø4X30	8 PCS			

STEP 4




③	 #8-Ø4X30	4 PCS	②		8 PCS
⑱	 80*80*2.5	2 PCS	⑲	 M6*12	8 PCS





3	 #8-Ø4X30	14 PCS	5	 #7 x 3.5x14	12 PCS
12		6 PCS			

STEP 14





Flip the drawer over and install the Y component and casters at the bottom




1	 KD Cam	8 PCS	4	 8 x 30MM	8 PCS


STEP 12






3	 #8-Ø4X30	4 PCS			


STEP 13





1	 KD Cam	4 PCS




STEP 6




1	 KD Cam	4 PCS	17	 L=428mm	1 PCS





STEP 7




①	 KD Cam	8 PCS	④	 8 x 30MM	8 PCS


STEP 8






⑤	 #7 x 3.5x14	2 PCS	⑪		1 PCS
①	 KD Cam	8 PCS	④	 8 x 30MM	8 PCS


STEP 9




Flip bracket


When opening the flip board, lift the movable flip board with both hands.
When closing the flip board, hold down the part shown in the diagram with both hands and press down to close it






5	 #7-ø3.5X14	4 PCS	7		2 PCS

STEP 10



If they cannot be locked after installation, they can be adjusted by themselves.

5	 #7 x 3.5x14	16 PCS	12		8 PCS

STEP 11

