4-Light Boho Brass White Fabric Drum Chandelier

Caution: Please turn off power before installation and read the manual carefully, we advise you contact professional electricians to install for safety purpose.

Product Features

Style:Boho
Material: Metal&Fabric
Color: White

Base Type:E26
Light Source Included: NO
Voltage: 120VAC
Wattage:40W

Package includes

1 x Chandelier
1 x Accessories Kit
1 x User's Manual



Installation Instructions

1. Press the acrylic diffuser into the lampshade.
2. Screw the center rod onto the threaded tube of the fixture body.
3. Screw the center rod onto the swivel joint.
4. Place the fixture body inside the shade. Align the upper ends of the flat bars with the notched cover at the top of the fixture body, then secure the flat bars to the notched cover with screws.
5. Secure the flat bars to the shade with screws, then tighten them with the ball nuts. Finally, adjust the flat bars so that they are properly aligned.
6. Slide the flat decorative cover onto the threaded tube of the fixture body, then thread on the hanging loop and tighten securely.
7. Fix the mounting crossbar to the junction box with the mounting screws.
8. Adjust the hanging chain to the desired length. Feed the fixture wires through the hanging chain, decorative ring, and canopy. Then use the quick link to connect the hanging chain to the fixture loop.
9. Use wire nuts to connect the incoming and outgoing wires. (Note:Connect the positive terminal to the positive terminal, the negative terminal to the negative terminal, and the ground wire to the ground terminal.) When wiring, take care to ensure that no wires are exposed.
10. Secure the canopy to the mounting crossbar using the decorative outer ring..
11. Install the bulb (bulb not included) into the lamp socket.
12. Turn on the power to check if the light bulb is working properly.

Installation complete.

Note: please use this product accordingly to its intended purpose, do not retrofit or remodeling the product. The warranty does not cover if the failure is caused by the third party product, or natural disasters.