KINCAID®

SOLID WOOD SINCE 1946

www.kincaidfurniture.com
phone :828-728-3261.

607-B44 Double Pedestal Dining Table Base
607-744 Double Pedestal Dining Table Top
Assembly Instructions





Hardware List

CODE	DESCRIPTION		QTY
A		Bolts Ï 5/16" * 1-3/4"	20
B		Flat Washer Ï 5/16" * 19	20
C		Lock Washer Ï 5/16"	20
D		Allen Key 100*50*5 MM	1

IMPORTANT NOTES

- Place all wooden parts on clean and smooth surface such as rug or carpel to prevent the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials,including staples and packing straps before you start to assemble.
- Do not tighten all crews and bolts until completely assembled.
- Keep all hardware out of the reach of children

Step 1: Begin assembly by attaching the connector panel (1) to the pedestal table base (2) with flat washer (B), lock washer (C) and bolt (A) Use dowel as guide. Tighten the bolt with Allen key (D).

Step 2: Put the table top (3) upside down on a flat and soft surface to prevent from scratching the table finishing.

Step 3: Attach the connector panel (1) to the table top (3) with flat washer (B), lock washer (C) and bolt (A). Use dowel as guide. Tighten the bolt with Allen key (D).

Step 4: Carefully turn table over adjust the leveler at the bottom of the pedestal table base till the table is even.

MADE IN VIETNAM