INSTRUCTION MANUAL



Parts List

Main frame	Front wheel	Rear wheels handrails	Cup holder
			
x 1	x 2	x 2	x 1

Foot rest	Backrest	Hexagonal wrench
		
x 2	x 1	x 1

Tip: Lay all parts on a clean floor. Watch our video guide by scanning the QR code on the right.

Step 1

Open the Main Frame  x 1

Pull the two side frames apart until fully open. You will hear the spring-loaded pins click into place. Fold both armrests upward until they lock into the upright position.







Step 2

Install the Backrest  x 1

Align both clips of the backrest with the screws and insert, then pull backward to secure firmly.







Step 3

Install Handrail Tubes & Rear Wheels  x 2

Install the handrail tubes and rear wheels into the main frame, ensuring the spring-loaded balls snap into the corresponding holes according to your desired height.









WARNING: When installing or adjusting height, align holes at identical positions on all four support legs to ensure stable operation.

Step 4

Install Front Wheel Tubes  x 2

Install the front wheel tubes into the main frame until the spring-loaded balls snap into the corresponding holes.







WARNING: When installing or adjusting height, align holes at identical positions on all four support legs to ensure stable operation.

NOTE: Secure the brake cables on the front tubes with included straps for proper brake operation. (Make sure the two cables are positioned outside the tubes).

Step 5

Install Foot Rests  x 2  x 1

Install the left and right foot pedals onto the corresponding front wheel tubes. Slide them down from the top and tighten the screws to ensure they are securely fastened.





Step 6

Install Cup Holder  x 1

Snap the cup holder onto the frame, then secure it with the locking clip.






Brake Adjustment



Use a wrench to turn the nut clockwise to loosen it. If the brake is too loose, pull the brake line outward. If it is too tight, pull it inward a little. After adjustment, tighten the nut counterclockwise.



Maintenance

1. The exterior of this rollator walker should be cleaned periodically with a soft damp cloth. Do not use abrasive cleaners or caustic chemicals.
2. Check the parts for any looseness, wear, or damage periodically. If any problems are found, adjust them first before use.
3. Please keep the walker in a cool, dry and safe place when not in use for long periods.

Warning

1. Before use, ensure the rollator is fully unfolded. Confirm that all screws are tightened and that both the brakes and especially the seat are securely locked in place.
2. Please lock the brakes before sitting down to prevent the walker from moving and causing falls.
3. Never lean forward onto the handles. This can cause the walker to tip forward and result in a fall.
4. Do not recline fully on the backrest, or it may cause the walker to tip over, resulting in a fall and serious injury.

Weight limited



Weight limited(140kg/310lbs)

Any problems with the product, please contact us through:
fvzzin@126.com