

ASSEMBLY INSTRUCTIONS


TS26-1376

PF078




WARNING !





Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.

Make sure no parts are missing or damaged before assembly.

PACKAGE CONTENT


Board Identification

Not actual size




BOARD IDENTIFICATION


Not actual size




1 x1




2 x1




3 x2




4 x1




5 x2




6 x1




7 x2




8 x1




9 x1




10 x1




11 x1




12 x1




13 x1



14 x1




15 x1




16 x1

BOARD IDENTIFICATION


Not actual size




17 x1




18 x1




19 x1




20 x1




21 x1




22 x1




23 x1




24 x1




25 x1




26 x1




27 x1




28 x1




29 x1



30 x2




31 x2




32 x2

BOARD IDENTIFICATION


Not actual size




33 x2




34 x2




35 x2




36 x2




37 x1




38 x2



39 x1























40 x1




41 x1

HARDWARE LIST

 A x98+2	 Ø15x9.5 B x98+2	 Ø6x30 C x64+2	 Ø5x40 D x21+2
 Ø3.5x12 E x28+2	 Ø5x40 F x4+1	 Ø20 G x98+2	 Ø3.5x12 H-1 H-2 H x1
 I-1 I-2x4+1 I-3x8+2 I x1	 J x20+2	 K-2 K-1 Ø3x14mm K x20+2	 L x8
 M x4	 N x8+1	 O-2 O-1 Ø3x14mm O x2	 P x4
 M4x19mm Q-1 Q-2 Q x4	 M4x19mm R-1 R-2 R x4	 S x4+1	 Ø3x16 T x20+2
 U x1	 Ø3.5x12mm Ø4x40mm V-1 V-2 V-3 V-4 V x2	 CL CR CL+CR x2	 DL DR DL+DR x2


Cam Lock Fastening System


Insert the cam bolt into the hole first, then insert the cam lock and lock it.




STEP 1


PF078









STEP 2







STEP 3

PF078




STEP 4







STEP 5


PF078






STEP 6







STEP 7


PF078







STEP 8











STEP 9

PF078



A	x 18

STEP 10




A	x 4

Ø5x40	
F	x 4

STEP 11


PF078



Ø6x30	
C	x 2

Ø15x9.5	
B	x 3

STEP 12





Ø6x30	
C	x 2


Ø15x9.5	
B	x 3


STEP 13

PF078












STEP 14










STEP 15


PF078









STEP 16











STEP 17

PF078







Ø6x30	
C	x 2

Ø15x9.5	
B	x 4

STEP 18






Ø6x30	
C	x 2

Ø15x9.5	
B	x 2

STEP 19


PF078



Ø3.5x12	
E	x 2


M	x 1


STEP 20




STEP 21


PF078








V	x 1



Ø15x9.5	
B	x 2

STEP 22






Ø6x30	
C	x 2



Ø15x9.5	
B	x 3

STEP 23


PF078



Ø6x30	
C	x2

Ø5x40	
D	x 2

STEP 24




Ø6x30	
C	x 2

Ø15x9.5	
B	x 3

STEP 25


PF078



Ø6x30	
C	x 2

Ø15x9.5	
B	x 4

STEP 26




Ø6x30	
C	x 2


Ø15x9.5	
B	x 2

STEP 27

PF078





STEP 28



STEP 29

PF078






V	x 1



Ø15x9.5	
B	x 2


STEP 30





A	x 31

STEP 31


PF078










STEP 32












STEP 33

PF078




STEP 34







STEP 35

PF078









A	x 7

STEP 36








Ø6x30	
C	x 2




Ø15x9.5	
B	x 3


STEP 37


PF078






STEP 38











STEP 39

PF078











STEP 40











STEP 41

PF078







Ø6x30	
C	x 3

Ø15x9.5	
B	x 4

STEP 42







Ø6x30	
C	x 2


Ø15x9.5	
B	x 3

STEP 43


PF078








Ø6x30	
C	x 2




Ø15x9.5	
B	x 3

STEP 44




Ø6x30	
C	x 4




Ø5x40	
D	x 4

STEP 45

PF078






Ø6x30	
C	x 4

Ø15x9.5	
B	x 8

STEP 46





Ø3.5x12	
E	x 4


M	x 2


STEP 47

PF078











STEP 48












STEP 49


PF078







STEP 50












STEP 51


PF078









STEP 52







STEP 53


PF078






STEP 54






STEP 55

PF078



STEP 56




Ø3.5x12	
E	x4


P	x 4

STEP 57

PF078





STEP 58



STEP 59


PF078






STEP 60


PF078






STEP 61

PF078







V-3	Ø4x40mm V-4
V	x 2

STEP 62


PF078




Step 3




Step 2



Step 1




STEP 63



Cabinet Slide arms

Drawer Slide brackets



FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard and Particle board

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

· Tighten all bolts and screws again within the first 2 weeks of assembly
· Check the tightness of all bolts every 2 months, tighten them if necessary



CLEANING

· Clean the surface of the MDF (medium - density fiberboard) or PB (particle board) with a lightly dampened cloth.
· Small amount of mild soap can be used if necessary
• Dry the surface immediately after cleaning.

⚠ DO NOT use bleach or alcohol detergent to clean the surface.
⚠ DO NOT apply wood treatment on parts made with MDF and PB.
Medium - density fiberboard and Particle board will swell and distort when suffer from water damage.
Make sure to dry the furniture immediately after cleaning