型号:DLS-K1 版本日期:A版 2025.5.5

Disposal and recycling information

Your product and/or its battery must be disposed of separately from household waste. When the service life of this product reaches the end, please comply with the requirements of national laws and regulations and hand it over to a local manufacturer with nationally recognized recycling qualifications for recycling. When disposing of your product and/or its batteries, separate collection and recycling will help conserve natural resources and ensure recycling is done in a way that protects human health and the environment.

Manufacturer: Xingtai Dalisi Toys Co., Ltd

Manufacture Address: No. 555 Rongtai Street Economic Development Zone, Xingtai City, Hebei Province, China.

US Importer: JUSTALENT INTERNATIONAL INC.


IMPORTER ADDRESS: 4215 E Airport Dr Ontario, CA 91761

E-MALL: support@garvee.com

MADE IN CHINA

Kids' Electric Vehicles

Product ID. PTG_336X




Scan for Support

Distributed by GARVEE.com

support@garvee.com

PART NO.	PART NAME	Quantity
1	Body	1
2	Seat	1
3	universal wheel	2
4	Hand shank	2
5	Instruction book	1
6	Remote control	1



1

Maintenance and maintenance

1.Before use, parents should check whether the main parts are in good condition, whether the batteries, chargers, wires, plugs, shells and other parts are damaged, whether the screws are loose, and whether there are potential safety hazards. If any damage is found, they should stop using until they are repaired.
2.After using for a period of time, use a small amount of lubricating oil to lubricate the iron parts of the vehicle to prevent wear and rust.
3.The vehicle should be placed away from the fire source and avoid long-term illumination. When storing, it should be placed upward and horizontally. In wet weather, the vehicle should be parked indoors or covered with waterproof cloth.
4. Vehicles should be kept away from hot objects, such as furnaces and heaters. Plastic parts may melt. When charging, keep away from flammable materials to prevent fire.
5. Please charge the battery in time after use. The charging must be operated by adults. If it is stored or not used for a long time, it must be fully charged first. Pull out the red main line and charge once a month to prolong the battery life.
6.Use dry soft cloth to wipe the vehicle, or use non wax furniture polishing material instead of soft cloth to wipe plastic parts to achieve smooth surface effect. Do not use chemical solvent to wipe the plastic parts of toys. Do not clean the vehicle with soap and water. Do not drive the vehicle in rainy or snowy weather. Water will damage the motor, vehicle circuit system and battery.
7.When you stop using or placing the product, please turn off the power supply of the product and turn all switches to the "stop" or "off" position.
8.Do not use fuses that do not conform to the specifications of this product.
9.Do not change the structure and circuit system of this product without authorization. The maintenance work must be carried out under the guidance of professionals or technicians.
10.Do not use toys for other purposes. Put batteries in with correct polarity.
11.It is forbidden to short circuit the positive and negative electrodes of the battery, and the non rechargeable battery cannot be charged.
12.Rechargeable batteries can only be charged under adult supervision.
13.Do not mix old and new batteries with different types of batteries.
14.The exhausted batteries should be removed from toys and properly handled to prevent children from playing.
15.When the toy is not used for a long time, the battery should be removed from the toy and properly handled to prevent children from playing.

12

11.The exhausted batteries should be removed from toys and properly handled to prevent children from playing.
12.When the toy is not used for a long time, take out the battery from the toy and handle it properly to prevent children from playing.
13.If the distance between the remote control and the control range is less than 3 meters, it means that the remote control battery is insufficient.Two aaa1.5v alkaline batteries should be replaced.
14.Before charging, please check whether the charger, battery and plug are damaged. If any damage is found, stop using it until it is repaired.
15.To reduce the risk of injury, adult supervision is required.Never use in roadways, near motor vehicles, on or near steep inclines or steps,swimming pools or other bodies of water; always wear shoes, and never allow more than 1 rider.
16.The battery on the vehicle is not replaceable.
17.The remote control is not a toy. It is for the adult use only, and should not be used by a child. A close adult supervision is always required. Reception range may change significantly with weather, battery, and other environmental conditions.

BE CAREFUL

- Only use the charger and battery specified by the manufacturer.
- Do not mix old and new batteries or different types of batteries.
- Battery terminals should not be short circuited.
- Do not turn on the battery and charger.
- Do not turn the battery upside down.
- Before charging, please check whether the charger, battery and plug are damaged. If any damage is found, stop using it until it is repaired.
- When charging, the charger will have a slight temperature phenomenon, which is a normal reaction, otherwise, the charger battery or circuit failure.
- The battery must be fixed with a pressure plate. If the car overturns, the battery will fall out and hurt children.
- The exhausted batteries must be disposed of by adults. Take out the used batteries from toys and recycle them properly. Do not discard them at will.
- If the product is stored or not used for a long time, it must be fully charged, the red main line must be pulled out, and the battery should be charged once a month to ensure the battery life.
- Chargers are not toys and children are not allowed to play.

11

咬口：CMYK 自翻A1

Product specification parameters

Battery	12V4. 5AH
Electric machinery	12V380#*2
Age of use	18-60 months
Maximum load	20kg
Dimensions	67x67x40CM
Speed	2km/h
Usage time	After full charge (about 8-12 hours),use for 1-2 hours continuously
Charger	Input AC 100-240V output DC12V-0.5A
Fuse	Self reset fuse

Note: Data and parameters vary with different configurations. Subject to modification without notice.

2

Safety warning:

Please tell your child and his playmates the following safety rules, and make sure they understand!
·Ensure your children use this product in a safe driving environment, such as home, garden or playground.
·Note that the vehicle is only suitable for driving on hard and flat roads. To ensure safety, driving in the following unsafe environments is prohibited:
A Ditch, small river, lawn, slope or uneven ground;
B public transportation road;
C may hit an obstacle that can cause injury;
D Other non-safe areas.

WARNING
- This product is not a toy. It is for the adult use only and should not be used by a child.
- **The age of using this product is 18-60 months.**
- The car carrying the weight of not more than 20Kg.
- To reduce the risk of injury, adult supervision is required.
- Protective equipment should be worn. Not to be used in traffic.The battery on the vehicle is not replaceable.
- Do not operate near motor vehicles, on or near steep inclines or steps,swimming pools or other bodies of water, always wear shoes, and never allow more than 1 rider.

Warning

1.When the remote control car is operated, the distance between children and adults should not exceed 10m.
2.The remote control is only allowed to be used by guardians and not allowed to be touched by children.
3.Before the remote control operation, read the manual carefully and carry out the empty car experiment. Only after getting familiar with it can children use it.
4.The remote control vehicle is not allowed to drive on the road of motor vehicles, water sources, obstacles and other places.
5.The remote controller shall not be soaked in rain or other ways to avoid line damage.
6.Do not mix old and new batteries with batteries of different brands.
7.If the remote control is not used for a long time, it is recommended to take out the battery to avoid battery leakage, corrosion of circuit board and damage of remote control.
8.In the process of remote control, the remote controller should be avoided from falling down.
9.The battery should be put in with correct polarity, and short circuit between positive and negative electrodes of battery is strictly prohibited.
10.Rechargeable batteries can only be charged under adult supervision. Non rechargeable batteries cannot be charged.


10

咬口：单色黑 自翻A2


型号:DLS-K1 版本日期:A版 2025.5.5

型号:DLS-K1 版本日期:A版 2025.5.5


Product installation instructions



3




5




4

咬口：单色黑 自翻B1



6



Open the battery cover of the remote control and insert two AAA1.5V dry batteries. Pay attention to the polarity of the dry batteries when inserting. Cover the battery cover and fix it with screws.
(Please follow the above steps to replace the battery, adult replacement is required)


Connection establishment
1. Install the battery of the remote control, turn on the vehicle power switch when the status light is on, the status light blinks, and the code is successfully verified.
2. Install the battery of the remote control, long press the forward and backward keys and do not let go. When the status light is on, turn on the power switch of the vehicle, and the status light blinks.

Kind reminder The remote control has the function of incorrect code can also be used; When you need to pair the remote control to the vehicle one-on-one, follow the "connection establishment" step.

Speed button Press the "S" speed control button to adjust the vehicle's low/medium/high speed.

Status lamp One low speed light, two medium speed lights, three high speed lights. When you press the "P" brake button, the indicator flashes simultaneously.

8




(Battery status: the blue light has sufficient power, the red light needs to be charged, and the red light flashing requires emergency charging)


7

Charging mode

In order to ensure safety, this product must be charged by adults.
The charging socket is located under the seat, and the charging procedure is operated according to the following figure.When the normal driving is slow, it should be charged to 8-12 hours in time, and the maximum should not exceed 20 hours.
It is recommended to charge for 4-6 hours before the first use, but not more than 10 hours.
Insert the charger into the charging hole (the whole vehicle is powered off).
This product has a charging protection function. When charging, all functions of the vehicle cannot be used.
Plug the charger into the power socket.



Note: Self-resetting fuse is 5A



Replace the fuse:

(1) if it is necessary to replace the fuse, first open the seat, take out the reset fuse, and then replace the reset fuse.
(2) the product uses a recoverable over-current fuse, When the current is too high, it will automatically cut off the power supply, and it can be automatically restored in 5-10 seconds.
(3) In order to prevent the fuse from cutting off the power supply, this product does not Can overload, maximum load.

9

咬口：单色黑 B2