Product Installation Instructions





Ax2



Bx4



Cx2



Dx2



Ex2



Fx1



Gx1



Hx1



Ix1



Jx1



J2x1



Kx1



Lx2



Mx2



Nx2



Ox1

1

1		46pcs +4pcs
Two in one screw(6x28mm)		

2		46pcs +4pcs
Two in one nut(10x12mm)		

3		20pcs +4pcs
Wood chipping(6x30mm)		

4	2pcs	4pcs +1pcs
Handle & screw(4x16mm)		

5		8pcs +2pcs
screw(3x10mm)		

6	 20pcs +4pcs  4pcs	
Guide& screw(3x12mm)		

7		4pcs +2pcs
Foot rubber pad		

8	 	4pcs +1pcs
Back plate buckle & Screw(3x16mm)		

		1pcs
AC/DC Adapter (12V⎓3.0A)		


1pcs


Double-head screwdriver, use as required

Product structure decomposition



1		16pcs	4	2pcs 4pcs		6		8pcs
2		16pcs	5		8pcs			4pcs



Use parts ① and ②

Step1



Step2



Step3





Use a screwdriver to lock in the direction of the "+" sign



Disassemble along the direction of "-" sign

Step 1





Step 2





Step 3







Twist in the direction of the plus sign

Step 4





Step 5





Step 6

5 x4



Don't beat the acrylic board too tightly, it will crack

Step 7

4 x1 x2



Exploded view of drawer guide rail





Step 1 : Pull the guide rail apart

Step 2 : Push the nylon buckle and pull outward ①



Step 8







Step 9





Use the same way to instalthe drawer

1		12pcs	6	 4pcs 12pcs	
2		12pcs	7		4pcs
3		12pcs			



Step 10





Step 11





Step 12

6 x2



This hole is for strengthening fixed hole customers can choose to install according to their needs.

Step 13

2 x2



Step 14



Step 15



Step 16





Step 17









Step 18

6 x2



This hole is for strengthening fixed hole customers can choose to install according to their needs.

Step 19

2 x4



Step 20

7



x4

Tear off release paper and stick the black foot pad on the board



Step 21





The light wire of the G board should be threaded out from the hole position of the back board

Step 22





Step 23





Step 24

2 x4



1		18pcs	8		4pcs
2		18pcs			1pcs
3		8pcs			



Step 25





Step 26





Step 27





Step 28





Step 29



2 x4

Step 30



1 x4

3 x4

Step 31



Step 32



As shown，When installing the drawer,
pull the guide rail out first, Slide beads are also pulled out.

Step 33



If a large gap is found after installing the drawer the slide rail can be moved up and down to adjust the gap

Step 34



If a large gap is found after installing the drawer the slide rail can be moved up and down to adjust the gap

Step 35

8 x4



Step 36



Step 37



User's Guide

Thank you for purchasing this product.

To use this product, please plug it into a 12V DC power supply.

Please use it if the product works normally after connecting to power.

Introduction

The box is an intelligent controller which integrates the charging function and the lighting control function, coming with 1 USB port and 1 type-C port, 2 touch buttons, a 24-color lighting control button, and a wireless charger.

Operation

This touch button is used to turn on/off lights and adjust brightness.

A. Long touch -> adjust the luminance.

This touch button is used to turn on/off the induction function.

A . Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller within 1 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.

B. Long touch to turn off the induction function.

C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.



This touch button is used to change 24 colors light. You can rotate the ring to choose colors, or click the ring to choose colors. Click in the middle of the ring, and reset to the white light.



ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If bubbles appear on the panel, remove the protective film.
3. If you have any questions when installing, please feel free to contact us. Thank you.