DIRECTIONS FOR USE

►1



SETUP Contrast code of remote control: Press the"contrastcode"button within 5 seconds after turning on the light,until the light flashes.

Product parameter

Input voltage:DC:3V
Standby current:3-10uA
Indoor Controllable distance :20m~30m
RF spenctrum:2.4GHz-2.483GHz

Moblie App download for scanning this QR: