CHRISTMAS TREE INSTRUCTION

WARNING: There are plastic caps on the end of each pole that are useless (like picture 2),please make sure remove them before assembling. If the caps were broken or missing, please don't worry.









Releasing all branches and leaves completely to make the tree fluffy.
(Slight drops of branches and flocking are normal)

