
ASSEMBLY INSTRUCTIONS




TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



2 – Persons Recommended

ASSEMBLY RATING



EASY ⟶ DIFFICULT

The Assembly Rating is a 5–point system showing the level of effort needed to assemble a specific product.

VERSION # 25-11-20

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**

  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling. Set up your workspace by laying the parts and hardware out separately, then begin!

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface


Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.




Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


DAYBED






PARTS

1 1pc




Right Arm

2 1pc




Left Arm

3 1pc




Back Panel

4 1pc




Front Side Rail

5 1pc




Back Side Rail

6 13pcs




Top Slat
997 x 45 x 18mm

7 12pcs




Bottom Slat
997 x 45 x 18mm

8 1pc




Trundle Front Panel

9 1pc



Trundle Back Panel


10 4pcs



Wooden Block


HARDWARE

A 8pcs




JCBB M8x20mm

B 4pcs



JCBC M6x50mm

C 1pc




Allen Wrench
M4 x 65mm

D 1pc




Allen Wrench
M5 x 70mm

E 40pcs



CSK Screw 16mm

F 56pcs




CSK Screw 32mm

G 4pcs



M6 Spring Washer

H 4pcs




M6 Flat Washer

I 6pcs












Roller

J 4pcs



L-bracket


packed in 2 cases

Carton	Designation	Part		Hardware
1	Right Arm	1	 x1	 A x 8pcs  B x 4pcs  C x 1pc  D x 1pc  E x 40pcs  F x 56pcs  G x 4pcs  H x 4pcs  I x 6pcs  J x 4pcs
	Left Arm	2	 x1	
	Top Slat	6	 x1	
	Bottom Slat	7	 x1	
2	Back Panel	3	 x1	
	Front Side Rail	4	 x1	
	Back Side Rail	5	 x1	
	Trundle Front Panel	8	 x1	
	Trundle Back Panel	9	 x1	
	Wooden Block	10	 x4	

ASSEMBLY INSTRUCTIONS


1

Part (1) x1pc
Part (2) x1pc
Part (4) x1pc
Part (5) x1pc
Hardware (A) x8pcs
Hardware (D) x1pc



2

Part (3) x1pc
Hardware (B) x4pcs
Hardware (C) x1pc
Hardware (G) x4pcs
Hardware (H) x4pcs





BACK VIEW

ASSEMBLY INSTRUCTIONS

3


Part (6) x13pcs
Hardware (D) x1pc
Hardware (F) x32pcs






4

Part (7) x12pcs
Hardware (E) x24pcs
Hardware (I) x6pcs






ASSEMBLY INSTRUCTIONS


5

Part (7) x12pcs
Part (8) x1pc
Part (9) x1pc
Part (10) x4pcs
Hardware (F) x24pcs




6

Part (7) x12pcs
Hardware (E) x16pcs
Hardware (J) x4pcs



ASSEMBLY INSTRUCTIONS

7



ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface.if the product wobbles or feels loose, double-check all bolts and/or screw are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift,don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.