Assembly Instructions


Thank you for your recent furniture Purchase.

To assist in assembly, it is highly recommended you loosely screw all bolts into each piece before you tighten them fully.


The frame used in the manufacturing process is produced using highly accurate machinery, and if you tighten one or two bolts before you have loosely screwed all bolts in place, you risk bending the frame out of shape, which will result in holes not aligning correctly.

If you have any problems with missing parts, damaged parts or assembling your product, please call our customer care line on **01278 764644** and one of our agents will be happy to assist you.


A×1




B×2




C×1




D×2




E×2



F×2




G×1



H×2



I×2




J×2



K×2




L×1



M×1



N×2



O×14




M8x40

P×30





M8x20

1




2












3




4







Q×14 	R×4 
S×24 	T×4 
U×12 	V×1 
W ×4  M4x40	X ×4 
Z×8  M8x30	


5







6












7




8







9



10



11



12

