

## ASSEMBLY INSTRUCTIONS

### Assembly Step:

- 1.Remove the lamp body carefully from the box.
- 2.As shown in step 1, put you hand on the lamp balance (1), move the balanced arm up and down. Adjust the shade (2) to the appropriate position. The base rotates 360° ( patented).
- 3.Plug into outlet.
- 4.Turn on the switch and enjoy your new lamp .

### Bulb Replacement:

- 1.Turn off/Unplug and allow to cool before replacing the lamp.
- 2.As shown in step2, remove the clip (4) and remove the lamp's protective glass.
- 3.Take off the used bulb and install a new bulb according to the specifications listed on the Bulb Replacement sticker.
- 4.Reinstall the protective glass, clip and screw (4) tightly in place.

### Attention:

- 1.Turn off/Unplug and allow to cool before cleaning lamp. Use a soft cloth only to clean . Oils from your fingers may damage the bulb.
- 2.IMPORTANT SAFETY INSTRUCTIONS-This portable lamp has a polarized plug (One blade is wider than the other.) as a safety feature to reduce the risk of electric shock. This plug will only fit one way into a polarized outlet. If the plug does not fit fully in, reverse the plug. If the plug still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully and easily inserted. Do not alter the plug.
- 3.THIS UNIT IS PROVIDED WITH A PROTECTIVE GLASS SHIELD WHICH PROVIDES ULTRAVIOLET RADIATION PROTECTION. USER IS CAUTIONED TO REPLACE THESE PROTECTIVE SHIELDS AFTER EITHER INSTALLATION OR REPLACEMENT OF TUNGSTEN HALGOEN LAMP.

**\*USE HALOGEN 50W(MAXIMUM) JC G6.35 (BULB INCLUDED)**

**\*PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE**

**\*SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

