

# Vitality MINI WATER COOLER CARTRIDGE REPLACEMENT GUIDE

little **Vitality**  
luxury<sup>®</sup>

To replace the Vitality filter cartridge for the Vitality water cooler, simply follow these instructions:

**Tip - Vitality Filter -**  
on first use flush filter under  
running water to clear out  
loose carbon



1. Rinse filter under a running tap gently shaking for 60 seconds.



2. Fill bottle with cold tap water



3. Close the bottle screw cap tightly



4. Fit the filter cartridge into the unit



5. Turn bottle upside down into unit.  
**Wait 1 hour before using your Little Luxury water cooler**




**Clean every  
3-6 months**

6. Pull back clip and remove tap reservoir cover in order to clean

1. To ensure your unit is kept clean, we recommend using the Little Luxury Crystal Spring<sup>®</sup> water cooler and water filter cleanser every 3 months.
2. To clean the bottle, use a few drops dishwashing liquid and half fill the bottle with lukewarm water.
3. If the flow of water stalls and stops flowing freely after the filter is reinserted or replaced, remove the filter and shake the filter to loosen the carbon and then reinsert the cartridge into the cooler.  
Note: **DO NOT USE HOT WATER.** Let the water drain and rinse with fresh water once or twice then drain.
4. When refilling the bottle with the water, it is suggested that you should tap off 1 glass of water on the side of the unit.

**IMPORTANT**  
**ENSURE THE BACK OF THE UNIT IS 15CM AWAY FROM THE WALL**

**CARTRIDGE REPLACEMENT GUIDE:**  
EVERY 1- 3 MONTHS MAX

 1-2 PEOPLE  
= 2-3 MONTHS

 MORE THAN 3 PEOPLE  
= 1-2 MONTHS

For use with municipal or city water. The contaminants or other substances removed or reduced by this water filter are not necessarily in all users' water. Do not use with water that is microbiologically unsafe, or of unknown quality, without adequate disinfection before or after the system. Systems that are certified for cyst reduction may be used on disinfected water that may contain filterable cysts. Individuals requiring water of certain microbiological purity should consult their physician. For your own health & safety use the original replacement cartridge.