



# ASSEMBLY INSTRUCTIONS










**YX7105**










# Detail View





# Part List

<b>A</b>  Side rail(1/2) - 2pcs	<b>B</b>  Side rail(2/2) - 2pcs	<b>C</b>  Horizontal bar HB&FB - 2pcs
<b>D</b>  Support legs - 3pcs	<b>E</b>  Legs - 6pcs	<b>F</b>  Support rail - 2pcs
<b>G</b>  Slats - 10pcs		

## Hardware List


<b>1</b> (Spare Hardware) 1pc  Ø8*25mm Wood dowel (9 pcs)	<b>2</b> (Spare Hardware) 2pcs  Ø4*16mm Wood screws (18 pcs)	<b>3</b>  100*20*2mm Metal bracket (2pcs)
<b>4</b>  M8*Ø36*17mm T-Nut (6pcs)	<b>5</b> (Spare Hardware) 1pc  (Ø12)1/4"*15mm Hex-Head bolts (9pcs)	<b>6</b>  Ø4*32mm Wood screws (4 pcs)
<b>7</b> (Spare Hardware) 2pcs  (Ø12)1/4"*38mm Hex-Head bolts (20pcs)	<b>8</b>  35*18*18*2mm Metal bracket (2pcs)	<b>9</b>  (1/4")4*60mm Allen key (1pc)

### ASSEMBLY TOOLS REQUIRED ( NOT INCLUDED )




DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT !

STEP 1:



4
6PCS


STEP 2:






7
6PCS

--	--


STEP 3:





1	
4PCS	
7	
12PCS	




STEP 4:






5	
8PCS	




## STEP 5:






2	8
	
16PCS	2PCS
	3
	
	2PCS



Make sure to tighten all the Hex-Head bolts, screws of the bed



## STEP 6:



1	6
	
4PCS	4PCS



Note: Do not lock the screws of the bed slats to the outermost edge of the bed slats, you need to leave a certain space at the edges, otherwise it will cause the board to break. Do not lock the bed slats on the edge of the wood, please hold firmly before screwing, hold it in place with one hand, then lock the screw.

