

C90135DR ASSEMBLY INSTRUCTION

"Why Our Furniture Comes in Smaller, Easy-to-Assemble Packages"

We believe that thoughtful packaging and design are essential to providing quality furniture that's better for the environment and easier on your wallet. That's why our products are shipped in fully knock-down, space-efficient packaging. This approach reduces the carbon footprint of transportation, minimizes packaging waste, and ultimately allows us to pass on significant savings to you. Additionally, our flat-packed designs make it simple to move and assemble your new furniture at home, saving you time and costly delivery fees. With a little consumer effort, you'll enjoy great furniture at a lower cost while making a greener choice for the planet. Take your time, follow the instructions, and enjoy watching your vision come to life--piece by piece."

We believe you will absolutely love your new furniture. Please immediately examine this product carefully. Any request for missing part or damage replacement must be received within 90 days of your receipt of the product. For some reason you want to return the product, please contact us directly before you decide to return your product to the retailer. Our Customer Service team can answer most concerns and can assist you with any questions you may have about your new product.

Please contact us first by emailing service@casepiece.com

Have these ready when you email:

- **Item Number**
- **PO #**
- **Purchaser Name**
- **Proof of Purchase**
- **Description of the problem and/or the Part Number needed**

Replacements for missing or damaged parts or hardware are normally shipped within 3 to 5 business days and we thank you for your patient.

The item must be returned in good condition, in the original box, with all original proof of purchase, parts and accessories, within the time frame specified by the retailer it was purchased from.

90-Day Limited Warranty Statement for Manufacturing Defects

Please read this Limited Warranty carefully. To maintain your Warranty, you will need to comply with the conditions stated here.

This warranty is for manufacturing defects only and does not cover damages as a result of misuse.

1. Our products sold comply with the description contained in this Warranty. All parts and products are warranted 90-Day from the original date of delivery except: parts and products used for commercial, contract, rental trade, institutional, or any other non-residential purposes; parts and products that have not been maintained in accordance with the care recommendations provided; parts and products damaged resulting from the consumer's improper assembly; or parts and products that are damaged or defective due to normal wear and tear.







2. To exercise rights under this warranty, proper documentation, i.e., photography, purchase order number, manufacturer's bar code label, and or any other pertinent information upon request is required. We reserve the right to repair or replace the product within the warranty period based upon the documentation received as support of a claim for consideration. We will not replace or repair any product if improper maintenance, improper handling, or improper use caused the damage. Any product sold from or modified by a Non-Authorized Dealer, Seller or Consumer will void the Warranty.

3. Cost of packaging and shipping to and from us is not covered by the warranty unless expressly arranged by us. This warranty does not extend to furniture that has been exchanged or replaced by us as settlement of an original claim of defective merchandise. This warranty does not extend to furniture that has been moved from delivery location on original purchase order.

We appreciate your business!



C90135DR ASSEMBLY INSTRUCTION

HARDWARES LIST

ITEM	DESCRIPTION	DRAWING	QTY
A	MINIFIX CAM LOCK		60 PCS
B	MINIFIX CAM BOLT		60 PCS
C	WOOD DOWEL (M6 x 25MM)		64 PCS
D	WOOD DOWEL (M8 x 25MM)		4 PCS
E	TRUSS M-SCREW (16MM)		12 PCS
F	HANDLE		6 PCS
G	6/8" NAIL		26 PCS
H	PLASTIC STRIP (H SHAPE)		1 PC
I	FLAT WASHER M6 x 19MM		4 PCS
J	SPRING WASHER M6 x 13MM		4 PCS







C90135DR ASSEMBLY INSTRUCTION

HARDWARES LIST

ITEM	DESCRIPTION	DRAWING	QTY
K	CSK SCREW M4 x 16MM		4 PCS
L	M4 ALLEN KEY (65MM)		1 PC
M	JCBC SCREW M6 x55MM		4 PCS
N	TIPPING RESTRAINT		1 PC





C90135DR ASSEMBLY INSTRUCTION

PARTS LIST

ITEM	DESCRIPTION	DRAWING	QTY
D1	TOP PANEL		1 PC
D2	LEFT PANEL		1 PC
D3	RIGHT PANEL		1 PC
D4	CENTER PANEL		1 PC
D5	SUPPORT RAIL		2 PCS
D8	BACK PANEL		2 PCS
D9	DRAWER HEAD		6 PCS
D10	DRAWER BACK PANEL		6 PCS
D11	DRAWER BOTTOM PANEL		6 PCS

C90135DR ASSEMBLY INSTRUCTION


PARTS LIST

ITEM	DESCRIPTION	DRAWING	QTY
D12	BOTTOM PANEL		1 PC
D13	TIPPING PANEL		2 PCS
19	DRAWER LEFT PANEL		6 PCS
20	DRAWER RIGHT PANEL		6 PCS
21	DRAWER BOTTOM SUPPORT RAIL		6 PCS
22	WOODEN LEG		4 PCS
D24	CENTER LEG		1 PC


*Note: All parts needed are shown in above picture.
Numbers only indicate the specific parts for easy assembly.

ASSEMBLY TOOLS REQUIRED


1. Screwdriver (not provide)



2. Hammer (not provide)



3. ~~Skip the power trip this time.~~



THINGS TO REMEMBER FOR ASSEMBLY


CHOSSES À SE SOUVENIR POUR UNE ASSEMBLEE

COSAS PARA RECORDAR EN UNA ASAMBLEA

MINIFIX BOLT

BOULON MINIFIX


PERNO MINIFIX



MINIFIX CAM

CAMÉRA MINIFIX


CÁMARA MINIFIX



WOOD DOWEL

CHEVILLE BOIS


PASADOR DE MADERA



C90135DR ASSEMBLY INSTRUCTION

STEP 1


NOTE : - The outer board is for protection of packaging only, not part of furniture. Please throw it before assembly.




PACKAGING ONLY-NOT A PART OF THE FURNITURE

STEP 2


					
B x 6	D x 4	I x 4	J x 4	M x 4	K x 4



STEP 2.2





STEP 2.3



TURN AROUND

STEP 2.1




C90135DR ASSEMBLY INSTRUCTION

STEP 3

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.


		
A x 4	B x 3	C x 4




STEP 4

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.

		
A x 4	B x 6	C x 4



TURN AROUND




C90135DR ASSEMBLY INSTRUCTION

STEP 5


NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.

		
A x 4	B x 3	C x 4



STEP 6


B x 6




STEP 7

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.

	
A x 4	C x 4

x 2



C90135DR ASSEMBLY INSTRUCTION


STEP 8

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.



A x 8



x 2



STEP 9

Reminber : - Holding the parts during assembly.



D13 board is used for ASTM at the back of products only



C90135DR ASSEMBLY INSTRUCTION



STEP 10

IMPORTANT : - When assembly D4, do NOT apply force or move D5 and D13. Hold then in position until D4 is fully inserted and secured.



STEP 11




Reminber : - Holding the parts during assembly.



IMPORTANT : - When assembly D5 and D13 in step 11, do NOT force or move D4. Hold them in position until D5 and D13 are secured.




C90135DR ASSEMBLY INSTRUCTION

STEP 12




IMPORTANT :-
When installing D3, do NOT force or move D5 and D13. Keep both parts aligned until D3 is fully secured.

STEP 13




C90135DR ASSEMBLY INSTRUCTION

STEP 14



STEP 15


Side with color paper must be the same.



C90135DR ASSEMBLY INSTRUCTION

STEP 16


x 6



STEP 17

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.


x 6



STEP 18

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.

x 6




C90135DR ASSEMBLY INSTRUCTION

STEP 19

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.

x 6




		
A x 6	B x 6	C x 12

STEP 20

NOTE : - Make sure arrows on each (A) point towards nearest edge with hole.



x 6




A x 12

STEP 21



x 6



C90135DR ASSEMBLY INSTRUCTION



STEP 22

x 6






STEP 23

x 6




STEP 24

x 6




C90135DR ASSEMBLY INSTRUCTION

STEP 25



IMPORTANT : -
Make sure two people move the dresser
if needed to avoid injury or product damage.
To avoid damaging, do NOT push, pull, or drag
the dresser across the floor.

STEP 26



ASSEMBLY COMPLETED