








La Jolla 30 Floating Vanity Installation Instruction



DIMENSIONS



WARNING !

In the hole on the wall, please be sure to be careful to avoid the internal cables and pipelines.






MATERIALS & TOOLS

Safety glasses, Pencil, Level, Tape measure, Stud Finder, Assorted screwdrivers, Assorted Wrenches, Drill, Screw gun, Caulking gun, Hammer, Screws, Nail anchors/Molly screws.





Vanity Installation

Step 1



PARTS

 A x2	 6*45 B x6	 C x2	 D x6
 3.5*15 E x2			




TOOLS REQUIRED


			
---	---	---	---

Step 2




Step 3


 6*45 B x4	 C x2	 D x6
---	---	---




Step 4




Step 5



Step 6



Step 7



Step 8

