



ASSEMBLY INSTRUCTIONS



Tools Recommended

THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.

*Need Parts or Assistance? Email us at **support@homejoyee.com***

IMPORTANT NOTICE

- This product contains small components, please ensure that they are kept away from small children.
- THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.
- Read each step carefully. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.
- Make sure all parts are included. Most parts are labelled or stamped on the raw edge.
- Work in spacious area, preferably on a carpet, near the place the unit will be used.
- Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.
- Move your new furniture carefully, with two people lift and carry the unit to it's new location.
- Never push, drag or pull your furniture (especially on carpet)



PLEASE DO NOT RETURE PRODUCT TO US IMMEDIATELY


If a part is missing or damaged, email our customer service.
We will gladly ship your replacement parts FREE of charge.

Need Parts or Assistance? Email us at ***support@homejoyee.com***

For Prompt, reliable service, please have your assemble instruction ready.



 WARNING	
	Children have died from furniture tipover. To reduce the risk of furniture tipover: • ALWAYS install tipover restraint provided. • NEVER put a TV on this product. • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heaviest items in the lowest drawers.
	

Assembly Instructions

[illegible]



STEP 1

A	X 1
	
M6*35	
E	X 4
	
M3*12	
CL	X 2
	




STEP 2

A	X 1
	
M6*35	
E	X 4
	
M3*12	
CR	X 2
	




STEP 3

B	X 2
	
$\phi 15 \times 10$	
C	X 2
	
$\phi 6 \times 30$	




STEP 4

A	X 4
	
M6*35	




STEP 5

B	X 4
	
$\phi 15 \times 10$	
C	X 4
	
$\phi 6 \times 30$	




STEP 6




STEP 7

C	X 4
	
Φ6*30	
D	X 4
	
Φ4*40	




STEP 8

A	X 6
	
M6*35	




STEP 9

A	X 8
	
M6*35	




STEP 10

B	X 8
	
φ15*10	




STEP 11

B	X 6
	
$\phi 15 \times 10$	
C	X 4
	
$\phi 6 \times 30$	
F	X 4
	
M3*16	



STEP 12

G	X 8
	
$\phi 4 \times 30$	





X2

STEP 13

A	X 4
	
M6*35	
B	X 4
	
Φ15*10	
E	X 4
	
M3*12	
DL	X 1
	
DR	X 1
	



Screw accessory A into board 9, then connect board 9 to boards 11 and 13 with accessory B.




STEP 14

A	X 4
	
M6*35	
B	X 4
	
Φ15*10	
E	X 4
	
M3*12	
DL	X 1
	
DR	X 1
	

Screw accessory A into board 10, then connect board 10 to boards 11 and 13 with accessory B.



STEP 15



STEP 16

