


Installation & Assembly



Assembly Instructions

Before beginning the assembly process, please read and save these instructions for reference.

Following these guidelines will ensure a smooth and successful assembly of your product.

1. Part Identification:

Carefully separate and identify all the parts included in your package. Confirm that you have all the components listed in the instruction manual. This step will help you avoid any missing or misplaced parts during assembly.

2. Work Surface:

To prevent any scratches or damage to the product, assemble it on a soft mat or a similar protective surface. This will provide a cushioned area for the components and protect the surfaces from unwanted marks.

3. Step-by-Step Assembly:

Follow the assembly instructions provided, proceeding one step at a time. Take care to understand each step properly before proceeding to the next one. This sequential approach ensures that the assembly is done correctly and minimizes the chance of errors.


4. Proper Screw Seating:

When attaching screws and nuts, it is essential not to fully tighten them until all screws are correctly seated. By partially tightening each screw and nut initially, you can ensure that they are aligned properly and fit securely before final tightening.


5. Avoid Over-Tightening:

While each screw and nut should be tightened correctly, it is crucial not to over-tighten them. Over-tightening can cause damage to the product or compromise its structural integrity. Use the appropriate amount of force to secure the components without excessive tightening.

Parts List




Hardware List




Code	Description	Quantity
A	JCBC SCREW M6 X 90MM	8+1
B	JCBC SCREW M6 X 70MM	10+1
C	JCBC SCREW M6 X 50MM	4+1
D	JCBC SCREW M6 X 35MM	16+1
E	JCBC SCREW M6 X 30MM	8+1
F	JCBC SCREW M6 X 15MM	8+1
G	BARREL NUT	8+1
H	WOOD DOWEL M10 40MM	4+1
I	STRAIGHT BRACKET	2
J	SPRING WASHER	26+2
K	ADJUSTER	4+1

Code	Description	Quantity
L	M4 ALLEN KEY	1
M	M4 ALLEN KEY	1


Step 1








Step 2









Step 3






E * 4	F * 8	J * 4	I * 2	L * 1
				

Step 4





A * 8	G * 8	H * 4	J * 8	L * 1
				


Step 5




Make sure the velcro tap is attached to the correct surface of tap A+B.

D * 16	M * 1
	



Step 6





X 4

K * 4


Step 7



You can adjust the height by rotating it left or right.

C * 4	M * 1
	

Step 8

