

## **ASSEMBLY INSTRUCTIONS**

### **5' BED**

**IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLING OR USING YOUR 5' BED FRAME.**

**PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

#### **HEALTH & SAFETY :**

DO NOT jump on this bed frame.

DO NOT use this bed frame if any parts are missing, damaged or worn.

DO NOT use this bed frame unless all fixings are secured.

Please keep small parts out of reach of children.

Always use on a level, even surface.

**WARNING: If this bed is placed on a non-carpeted floor you must place some protection under all legs to stop the bed frame from moving. If this is not adhered to there is no guarantee if the bed frame collapses.**

#### **CARE & MAINTENANCE:**

Assemble in the room of use.


Periodically check all screws & fixings to ensure they are secure.









DO NOT push the bed frame as this will damage the legs.

Always lift the bed with two people to reposition.

Keep any sharp objects away from the frame.







PART LIST				HARDWARE LIST (FOUND IN BOX 1)		
PART	DESCRIPTION	BOX	Qty	PART	DESCRIPTION	QTY
1	Headend	1	1	A	M6 x 16mm JCBC Screw 	8
2	Footend	1	1	B	M6 x 50mm JCBC Screw 	4
3	Side Support	2	2	C	M6 Nut 	10
4	Side Frame	2	2	D	M6 x 35mm JCBC Screw 	6
5	Mid Support	2	1	E	Double Slat Cap 	13
6	Base Leg	1	3	F	Single Slat Cap 	26
7	Slat	3	26	G	M8 x 50mm JCBC Screw 	2
<b>**M4 Allen Key &amp; M5 Allen Key provided</b>				H	M8 Nut 	2
				I	Finial 	4

**Step 1:** Fix the Side Support (3) to the Headend (1) and Footend (2) using hardware part (A), but do not fully tighten the screw yet.


**DO NOT use any power tools as this may damage the frame and will invalidate any claim.**




**Step 2:** Place the side frame (4) at the bottom of the side support (3) and tightly secure using hardware parts (B) and (C).  
**DO NOT use any power tools as this may damage the frame and will invalidate any claim.**




**Step 3:** Place the mid support (5) on top of both side frames (4) and tightly secure using hardware parts (G) and (H).  
**DO NOT use any power tools as this may damage the frame and will invalidate any claim.**



**Step 4:** Fit the base legs (6) to the mid support (5) according to the holes at the side using hardware parts (C) and (D).  
**DO NOT use any power tools as this may damage the frame and will invalidate any claim.**



**Step 5:** Push hardware part (E) into the mid support (5), then place hardware part (F) onto the end of each slat (7).  
**DO NOT use any power tools as this may damage the frame and will invalidate any claim.**



**Step 6:** Insert the slats (7) to hardware part (E) and press firmly into the side supports (3). Finally insert hardware part (I) to the headend (1) and footend (2).  
**DO NOT use any power tools as this may damage the frame and will invalidate any claim.**

