


WARRANTY

We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.



NOTE:

This brochure contains IMPORTANT safety info. Please read and keep for future reference.

MAINTENANCE AND WARNING

- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.




Weight Limitation

220LBS

PARTS LIST


Ax1

Seat




Bx1

Spider base



Cx5

Casters




Dx1

Gas lift



Ex1

Bottom mechanism



Fx1

Metal base cap




HARDWARE LIST

Gx1
M6
Allen Key




Hx4
M6*20mm
Screw




SPARE

Hx1
M6*20mm
Screw




Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.

ASSEMBLY INSTRUCTIONS




Place the chair seat/back assembly on clean padded surface.

STEP 1: Insert casters C to bottom of the spider base B.




STEP 2: Attach the metal cover F on top of the spider base B then insert the gas lift D to the center hole of the base B.



Please don't fasten it until all bolts connected correctly.

STEP 3 :Use bolt H and allen key G to attach mechanism E to bottom of the seat cushion A, make sure the holes on under seat align with metal plate,then fasten bolts to secure.

Set the chair seat A upright and align top of gas lift D and center hole of metal plate B, push down to secure.



STEP 4 :Assembly completed.