


TWIN BED





Thank you for purchasing this **TWIN BED**!

Before you start, here is some helpful advice:


1. We suggest you spend a short time reading through this leaflet and then follow the simple step by step instructions.
2. Owing to the size and weight of the bed, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approx assembly time: 45 minutes.
3. Please do not use any tools other than those provided or recommended in these instructions.
4. Please do not throw away any of the packaging or the instruction until you have checked all the components and hardware and the furniture is fully assembled. Please ensure that the packaging is disposed of in a safe environmentally friendly way.
5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that has been provided.
6. Please keep all fitting out of reach of children.



Hardware:

| | | | |
|---|--|---------------|-----|
| A |  | Bolt M6x20mm | x28 |
| B |  | Flat Washer | x4 |
| C |  | Rubber Insert | x16 |
| D |  | Allen Wrench | x1 |

Component:



| | | |
|---|-------------|----|
| 1 | Headboard | x1 |
| 3 | Side Rail | x2 |
| 5 | Single Slat | x8 |

| | | |
|---|-------------|----|
| 2 | Footboard | x1 |
| 4 | Double Slat | x4 |
| 6 | Low Post | x2 |


TWIN BED




STEP 1:

Insert **Low Post (6)** into **Headboard (1)** as shown.

Attach by using **Flat Washer (B)** and **Bolt (A)** from the holes on the back of **Low Post (6)** and **Headboard (1)**.

Use **Allen Wrench (D)** to tighten **Bolts (A)** clockwise until secure at this step.



| | | |
|---|---|---|
|  |  |  |
| Ax4 | Bx4 | Dx1 |

Hardware & Tool required



STEP 2:




Take out all **Double Slats (4)**, **Single Slats (5)** and **Side Rails (3)** and place them as shown.

Insert one end of **Single Slats (5)** into **Rubber Insert (C)**, then insert them into the corresponding holes on one piece of **Side Rail (3)** as shown.

Attach **Double Slats (4)** to the same **Side Rail (3)** by using **Bolts (A)**. Do not fully tighten **Bolts (A)** with **Allen Wrench (D)** yet. Repeat above for the other **Side Rail (3)**.

Use **Allen Wrench (D)** to tighten all **Bolts (A)** clockwise until secure.



| | | |
|---|---|---|
|  |  |  |
| Ax16 | Cx16 | Dx1 |

Hardware & Tool required

TWIN BED

STEP 3:


Insert **Bolts (A)** into the bottom holes on the assembled **Headboard (1&6)** & **Footboard (2)** by hand.

Leaving 0.3~0.4inch space of the thread of **Bolts (A)** as shown for inserting the notch of assembled **Side Rails (3&4&5)**.

Insert the notch of assembled **Side Rails(3&4&5)** into the space left on the **Bolts (A)**.

Screw **Bolts (A)** into the top holes on the assembled **Headboard (1&6)** & **Footboard (2)** as shown.

Tighten **Bolts (A)** with **Allen Wrench (D)** after all assembled.



Assembly is completed. Your bed is ready to be enjoyed now!

| | |
|-----|-----|
| | |
| AX8 | Dx1 |

Hardware & Tool required