




ASSEMBLY INSTRUCTION


For Hard-wired



For Plug-in



All electrical components must be installed by a licensed electrician in accordance with the National Electric Code and the appropriate local electrical codes.



You will need 1-Medium
60 watts Max Bulb not included
USE LED BULBS FOR EXTENDED USE
THIS FIXTURE IS DRY RATED

How to Install

This is a convertible piece. Installation steps for both Hard-Wire and Plug-In options are below.

For Hard-wired installation, please proceed as follows:

1. Remove the plug wires from the fixture wires.
2. Remove the Nut (D) from the bottom of Back Plate (B) and cover the hole with plug (E).

3. Attach the shade(H) onto the socket(G), and then use the socket ring(I) to lock it.

For Plug-in installation, please proceed as follows:

1. Connect Rod (F) to the bottom of Back Plate (B).
2. Determine the desired location you'd like to put this fixture on the wall, and mark two points on it with same distance as between the holes on the Back Plate (B).
3. Drill the holes at the marked points and insert the anchors into the holes in the wall, Attach the mounting plate onto the wall by anchor screws.
4. Attach the Back Plate (B) onto mounting plate.
5. The length of the swing arm(C) can be adjusted to length.

Part Number

Part Numbers

A. Mounting Hardware
(1) Wire Nut
(1) Mounting Plate
(4) Mounting screws
(4) Anchors

B. (1) Back Plate: 7" x 4.25" x 1"H
XME601MKBKP7IN

C. (1) Swing arm

D. (2) Connector

E. (1) Plug

F. (2) Rod; $\varnothing 0.37$ " x 11.5"

XME601MKROD11.5IN

G. (1) Socket

H. (1) Shade; $\varnothing 15$ " x 9"H
XME601MKSHA15IN

I. (1) Socket Ring

