



Corner Glass Cabinet

Assembly Instruction




List of Parts



Hardware

A x 24+2




Ø6 x 34mm

B x 24+2



Ø15 x 10mm

C x 2




D x 48+2




Ø3.5*12mm

E x 2



F x 2



G x 2




H x 24+2



Ø25mm

I x 1



J x 6+1



Ø3.5*35mm

K x 15




L x 2+1



Ø3.5*14mm

M x 2



N x 3




O x 3+1



Ø6*25mm

P x 20+2



Ø8 x 30mm


Q x 8+1



Ø3*16mm


STEP1

J x 6




Ø3.5*35mm

P x 4




Ø8 x 30mm



STEP2

A x 12





Ø6 x 34mm

Q x 4



Ø3*16mm

M x 1




STEP3

B x 6




Ø15 x 10mm


P x 4



Ø8 x 30mm



STEP4




STEP5

B x 6




Ø15 x 10mm

P x 4



Ø8 x 30mm




STEP6






A x 6




Ø6 x 34mm





STEP7

A x 6	Q x 4
	
Ø6 x 34mm	Ø3*16mm
L x 2	
	
Ø3.5*14mm	
I x 1	
	
M x 1	
	




STEP8



B x 6

Ø15 x 10mm
P x 4

Ø8 x 30mm




STEP9



STEP10

B x 6

Ø15 x 10mm
P x 4

Ø8 x 30mm




STEP11


D x 24



Ø3.5*12mm



Remove protective film
on the mirror panel.




STEP12


D x 24





Ø3.5*12mm




Remove protective film
on the mirror panel.





STEP13

N x 3

O x 3

Ø6*25mm




STEP14

H x 24

Ø25mm




STEP15

K x 15




STEP16


F x 2








E x 2



G x 2



STEP17



STEP18

