

CHEST

ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1 . Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !

- 1 . Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2 . This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION


A.



CHEST

1 PC

B.



RIGHT FRONT LEG

FR

1 PC

C.



LEFT FRONT LEG

FL

1 PC

D.




RIGHT BACK LEG

BR

1 PC

E.



LEFT BACK LEG

BL

1 PC

HARDWARE IDENTIFICATION

1.



BOLT

8 PCS

2.



LOCK WASHER

8 PCS

3.



FLAT WASHER

8 PCS

4.




ALLEN WRENCH

1 PC


NOTE : PHILLIPS HEAD SCREW DRIVER IS REQUIRED IN THE ASSEMBLY PROCESS. HOWEVER, MANUFACTURER DOES NOT PROVIDE THIS ITEM.

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2



ANTI - TIPPING KIT





PARTS IDENTIFICATION

A. CHEST



1 SET


HARDWARE IDENTIFICATION

- | | | | |
|----|--|-------------|--------|
| 5. |  | SHORT SCREW | 1 PC. |
| 6. |  | LONG SCREW | 1 PC. |
| 7. |  | CABLE TIE | 1 PC. |
| 8. |  | L BRACKET | 2 PCS. |

This tip restraint must be attached to a wall stud using long screw enclosed.


STEP 1

Attach a bracket securely to the back top rail of the chest using short screw provided, through the smaller hole.



STEP 2

Locate the other bracket on the wall over a wall stud and two inches below the mounting bracket secured to the back of chest. Attached to the wall stud using the long screw provided, through the smaller hole.



STEP 3

Place the chest into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed. Confirm that the strap is securely laced and locked.

