

Installation & Assembly



IMPORTANT SAFETY INFORMATION

- PLEASE READ THE ENTIRE INSTRUCTION MANUAL BEFORE BEGINNING INSTALLATION.
- IF THIS MANUAL DOES NOT MATCH YOUR INSTALLATION, PLEASE CONTACT US.



WARNING



The product is intended for indoor use only. The product must be assembled and used in accordance with the provisions of the manual. Personal injury and/or damage to the product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The seller does not assume any responsibility or liability with respect to any injury/damage caused by incorrect assembly or improper use.



Before starting assembly, verify that all parts are included and undamaged. Do not use damaged or defective parts. If you require replacement parts, please call technical support or email customer service.



To avoid potential damage to the product and flooring during assembly, use a blanket or underlayment to lay out parts.



Assembly and maintenance must be performed by adults only.

Keep children and pets away during assembly.

Do not allow your children to climb or hang on the vanity, which may cause a tip-over accident.



Wear gloves during the assembly and/or disassembly process.



Periodically inspect screw tightness after assembly. If necessary, retighten to ensure structural integrity.




Do not exceed the Max Load. Doing so may cause instability and tip-over, resulting in serious injury and/or death.













Consult plumbing professional for specific installation questions and consult local codes as applicable.

This product is designed to be installed against a permanent wall structure and must be securely attached to wood studs and solid concrete.


Use only through-wall plumbing fixtures designed for single-hole or 3-hole, 4" centerline faucets.






Ø6 x 34mm

(A) x 36




Ø15 x 9.5mm

(B) x 36




Ø6 x 30mm

(C) x 26



Ø4 x 12mm

(D) x 16




Ø4 x 35mm

(E) x 3




Ø4 x 15mm

(F) x 36




Ø4 x 19mm


(G) x 6




(H) x 4



(I) x 6




(J) x 1



(K) x 3




(L) x 4




Ø8 x 40mm

(M) x 2




Ø5 x 55mm

(N) x 2



2.5m


(O) x 1




Ø5mm

(P) x 1



Installation Guide






1




2




3




4




5






6







7








8







9




10











11




12




13





14




15












17












18















A Wood Studs



B Solid Concrete



Installation Instructions:

A. For Wood Stud Walls



- 1) Locate and mark the stud centerline. Mark the hole positions where the centerline aligns with the unit's holes.
- 2) Secure the unit to the wall using screws. If the stud spacing is 12" or 24", securing the unit to a single wood stud is sufficient for stability.

B. For Solid Concrete Walls

- 1) Drill pilot holes in the wall at the appropriate height.
- 2) Tap wall anchors in.
- 3) Secure the unit to the wall using screws.



22

Note: Allow the Basin to remain undisturbed for 24 hours to achieve full adhesion.




2.5m

○ x 1



Note: Be careful not to pinch your hand.



Optional: For added stability and waterproofing, apply 100% silicone adhesive along the edge of the tape before attaching the Basin. Avoid applying adhesive directly to the tape.