







Shoe Storage Bench



Parts - Identify parts before assembling.



Hx 1
Moulding



Lx 20
Cam lock



Mx20
Cam screw



Nx31
Wood dowel



Ox8
Long screw



Px14
Short screw




Rx3
Handle screw



Sx3
Handle


Assembly

1 Insert hardware into assembly pieces as shown.




Assembly cont'd


- 2** Insert shoe dividers (D/E) into slotted shoe panel (C) so that panels are in the following order: D, E, E, D



- 3** Attach drawer dividers (B) to the top side of drawer panel (F) using long screws (O). The top side of panel F has the wider-set holes.




- 4** Insert 4 cam locks (L) into the side predrilled holes on shoe dividers (D). Attach drawer panel (F) to shoe dividers (D/E). Turn cam locks to lock assembly.




5


Insert 4 cam locks (L) into the side predrilled holes in (B). Attach top panel (A) to drawer dividers (B). Turn cam locks to lock assembly.

**6**

Attach bottom panel (G) to shoe dividers (D) and (E).

**7**


Screw bottom panel (G) into place using long screws (O). Insert 2 cam locks (L) into predrilled holes in moulding (H). Attach moulding to bottom panel (G). Turn cam locks to lock assembly together.



Assembly cont'd


8

Insert 10 cam locks (L) into predrilled holes on the sides of assembly that line up with cam screws in side panels (I/J). Attach side panels (I/J) to assembly. Turn cam locks (L) in assembly to lock assembly together.




9

Attach back panels (K) using short screws (P).



10


Remove adhesive backing from hook and loop strips on the underside of cushion. Position on the top side of top panel (A) and press into place.

**11**

Unfold drawers and lay bottom panel inside as a liner / base.

Attach handles: fit handles (S) on drawer fronts and secure from inside the drawer with screw (R).

Insert drawer into cubby. FINISHED.



NOTE: Screws and washers may already be screwed into handles.

