

installation instructions:

TIMBERTHANE RAFTER TAILS

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

Corbels are not load-bearing, decorative use only.

TOOL & MATERIAL CHECKLIST

- | | |
|---|---------------------------------------|
| ☐ Electric Drill | ☐ Wood blocks |
| ☐ Drill bit for pilot hole | ☐ Adhesive |
| ☐ Countersink bit | ☐ Caulking gun |
| ☐ Screws | |
| ☐ Caulk | |


IMPORTANT INFO

- Clean installation surface and corbel of all dirt and dust with a clean cloth or dry sponge.
- It is highly recommended that you paint/finish the rafter tails before installation.
- Once installed, you can apply any necessary touch-up paint/finish.
- Measure and mark the location where the bracket is going to be installed.
- All TimberThane rafter tails are decorative only and are built as solid hollow channels to slip over wood blocking strips for easy installation.
- Wood blocking strips should fit snugly into the back of bracket.

INSTALL INSTRUCTIONS:

1. Attach wood blocks to surface with screws.
2. The top and back pieces of rafter tail will easily "slip" over wood blocking strips.
3. Screw through side of bracket into wood blocks to properly secure.
4. Use acrylic caulk to seal edges of bracket against surface after installation.
5. Fill in any holes with caulk and smooth the surface with finger.
6. Let caulk dry. Once dry, lightly sand with extra fine sandpaper.
7. Touch up rafter tail with paint as needed.

EXAMPLE DIAGRAM:



Industry leading manufacturer of urethane, PVC, wood, rustic, and metal millwork

We Can Help. Call (866) 607-0453

www.ekenamillwork.com