

Metal Storage Cabinet

Instruction Manual

Your new Metal Storage Cabinet has arrived and it will make your life so much easier. That's why we put so much effort into designing it to perfectly fit your needs.



But first things first, we need to install it!


When we say 'we', we mean we're going to guide you, step by step.

We created this instructions manual so that you won't feel overwhelmed and We also know that sometimes things just don't seem to fit, so don't hesitate to contact with our Customer Associate if you have questions or need help!


Missing A PART? DON' T WORRY, WE GOT YOUR BACK!

Compare the sketch on the next page with your package. Are all the pieces there? However, sometimes error happen, so if anything is missing or damage, just send us an email and we will make sure to fix it!







A*1




B*1




C*1




D*1




E*1




M*1




F*1




H*1




I*2




CC*1





K*1




J*1




G*4





N*39




O*8



L*3



Q*4




S*2




RR*32




U*4




V*8




W*2



T*2









1

L*3



Let's start with the back of the cabinet. Take Back Panel pieces A & B Place them on the floor

The frame with rectangular holes must be pointing upwards. Overlap & align the holes of the interior frames, Fasten in place using L*3 screws (like shown in the picture)




2

N*6 

Simply take the side plate C&D and put N*3 screws on each side to hold them in place.








Note that Part C is on the left side and Part D is on the right side.

If they are misplaced, it will affect the assembly.






3

N*8 




4

Take Top Frame H*1, Fasten in place using N*7 screws through the holes in each corner.

N*7 

5

When placing Part F, place the notched side facing forward.
Install the set screws from middle of the bottom by using N*2.



N*2 

6



N*16






G*4



G



Bend the Part G, install the 4 legs by
using G*4 and N*16



7







0*8



V*8




CC*1



8

RR*32 

In this step you just need to tighten the RR*32 screws (like shown in the picture).



9

Take S*2 bolt screws & insert a metal ring on it.

Insert the bolt in the bottom frame's hole (like shown in the picture below).

Take door K1 & J1.

S*2









Place the door with the bottom hole in the bolt.

Press the arch at top of the door to fix the door in the upper frame.

Make sure it is securely fastened up and down .


Move the door back & forth

to test it .



10


Q*4





T*2



U*4




Take Q *4 magnetic pieces, install 4*Q at each corner of the door.
Last, Install the door handle T*2 by using U*4.




11

W*2



Push the metal cabinet against the wall. Mark the places on the wall there you are going to drill. Take the Percussion Drill. Drill holes in the marked places.

Take wall plugs W*2 insert in the drilled holes using a hammer.



Your metal cabinet is ready to use!

THANK YOU FOR BEING PART OF OUR STORY.

