


Assembly Instructions




Side Table

Model No.
HOGA-SL0138

Contact Us




We're here to help you.



Your satisfaction is our top priority. If you encounter any issues with this product, such as missing or damaged parts, we're here to help. Please retain the original packaging and take photos of the packaging and the product, then contact us as soon as possible.


Warm Tips

1. Carefully read these instructions and keep them for future reference.
2. Check the parts list and confirm everything's there before starting assembly.
3. When assembling, put all parts on a soft, smooth surface like a carpet to avoid scratches.
4. Don't fully tighten screws until all parts are confirmed in place to avoid misalignment.





We recommend using hand tools for assembly.


If an electric screwdriver is used, reduce power and torque to avoid damage to the product.



AVOID SCRATCHES

In order to avoid scratching, this furniture should be assembled on a soft surface, such as a rug.




















⚠ Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.

Parts List



1  1 pc	2  1 pc	3  1 pc	4  1 pc
5  1 pc	6  2 pcs	7  2 pcs	8  2 pcs

Hardware List


A	B	C	D	E	F
 Ø6x35mm 16 pcs	 Ø15x12mm 16 pcs	 M5x50mm 2 pcs	 M4 1 pc	 M6x25mm 8 pcs	 Ø12 8 pcs
G	H	I	J	K	L
 Ø8x30mm 10 pcs	 M8x75mm 10 pcs	 M8 10 pcs	 M8 10 pcs	 M8 10 pcs	 M14 1 pc
M	N	O			
 Ø44 10 pcs	 Ø22 26 pcs	 1 pc			

Installation of Cams and Pins


Read each step carefully before starting. Each step of instruction should be performed in the correct order. If these steps are not followed in sequence, assembly difficulties may occur.






Screw the pin into the hole. Set the cams correctly by aligning the head of the cams with the lock pins. Lock the cam by turning the cam head with a screwdriver until it is tightened. Please do not use an electric screwdriver to assemble the unit.




1




G	H
	
Ø8x30mm	M8x75mm
1 pc	2 pcs




2




I	J	K	L
			
M8	M8	M8	M14
2 pcs	2 pcs	2 pcs	1 pc


Step 1




Step 2





Step 3








Step 4









3

G	C	D
		
Ø8x30mm	M5x50mm	M4
1 pc	2 pcs	1 pc






4

G	H	A
		
Ø8x30mm	M8x75mm	M6x35mm
8 pcs	8 pcs	4 pcs






5

B	I	J	K	L
				
Ø15x12mm	M8	M8	M8	M14
2 pcs	4 pcs	4 pcs	4 pcs	1 pc






6


B	I	J	K	L
				
Ø15x12mm	M8	M8	M8	M14
2 pcs	4 pcs	4 pcs	4 pcs	1 pc




7






D	E
	
M4	M6x25mm
1 pc	8 pcs







8






A

M6x35mm
8 pcs




9



10




11




B


Ø15x12mm
8 pcs



12



F	M	N
		
Ø12	Ø44	Ø22
8 pcs	10 pcs	26 pcs



⚠ Caution! Tap lightly

Thank you for your support!

