




ASSEMBLY INSTRUCTIONS



Tools Recommended

THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.

IMPORTANT NOTICE

-This product contains small components, please ensure that they are kept away from small children.

-THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.

-Read each step carefully. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.

-Make sure all parts are included. Most parts are labelled or stamped on the raw edge.

-Work in spacious area, preferably on a carpet, near the place the unit will be used.

-Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.

-Move your new furniture carefully, with two people lift and carry the unit to it's new location.

-Never push, drag or pull your furniture (especially on carpet)




PLEASE DO NOT RETURN PRODUCT TO US IMMEDIATELY


If a part is missing or damaged, email our customer service.
We will gladly ship your replacement parts FREE of charge.

For Prompt, reliable service, please have your assemble instruction ready


 WARNING	
	Children have died from furniture tipover. To reduce the risk of furniture tipover: • ALWAYS install anti-tip device provided. • NEVER put a TV on this product. • NEVER allow children to stand, climb or hang on any drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heaviest items in the lowest drawers.
	This is a permanent label. Do not remove!

The installation direction should be aligned with the instructions to prevent plate breakage caused by product tipping during installation.




Ax10  Ø6x35mm	Bx10 	Cx8  6x30mm	Dx24  4x12mm	Ex6  4x40mm	Fx2  4x40mm	Gx12  3x14mm
Hx8 	Ix4 	Jx4  3.5x12mm	Kx2 	Lx22  4x12mm	Mx2 	Nx4 
Ox4 	Px2 	Qx2 	Rx2 	Sx2  3.5x12mm		

Step 1



Lock the screw (A) to part ② ④, as shown.




Ax6




Ø6x35mm

Step 2




Assemble part ② and parts ③ ⑧, then put the eccentric (B) into the hole and use a flat-blade screwdriver to turn it clockwise to tighten, the installation position is as shown below.




Bx3



Step 3



Attach part ④ to assembled unit with eccentric (B)
Turn it clockwise to tighten. The installation position is as shown below.




Bx3



Step 4

The installation direction should be aligned with the instructions to prevent plate breakage caused by product tipping during installation.



Insert the dowel (C) into parts ② ④ first, then insert part ⑨ along the slot, and then attach part ⑥ to assembled unit with screw (E). The installation position is as shown below.

Cx4




6x30mm

E x4



4x40mm

Step 5



Use screw (L) to lock support leg (O) to part ⑥ .
The installation position is as shown in the figure below.

Lx20




4x12mm

Ox4





Step 6



Lock the screw (A) to part ① first, then install the anti-tipping devices (K) to the part ① with screw (L). Use the screw (G) to lock the magnetic touch (Q) to the part ①. The installation position is as shown below.




Step 7



Insert part ⑦ along the slot first. Then insert the dowel (C) into parts ② ④, attach part ① to assembled unit with eccentric (B), turn it clockwise to tighten, And then use screw (F) to attach part ① and part ③. The installation position is as shown below.



Step 8




Gx8



Hx8



Step 9



Drill a small hole in the wall first, then plastic nail (M) into the wall and then use screws (E) to fix the cabinet to the wall. The installation position is as shown in the figure below.

Ex2




Mx2



Step 10


Install the layer support (N) to part ② ④, as shown.
Then place part ⑤ parallel in the middle of the cabinet.



Nx4




Step 11



First, use the screw (D) to lock the hinge (I) to part⑩⑪ , Then use the screw (S) to lock the iron plate (R). The installation position is as shown in the figure below.

Sx2  3.5x12mm	Rx2 	Ix4 	Dx8  4x12mm
---	---	---	---


Step 12



Use the screw (J) to lock the handle (P) on part⑩⑪

Px2 	Jx4  3.5x12mm
---	---

Step 13





Use the screw (D) to lock the hinge to part ② ④, as shown.

Dx 16



4x12mm

Step 14



Hinges Adjustment Tips



Loosing screw (D) can adjust the door panel vertically.



Loosing screw Z can adjust the door panel horizontally.



Loosing screw Y can adjust the door panel in-and-out.

