








ASSEMBLY INSTRUCTIONS





REVISION : A


STEP 1

Take out Assembly Instruction sheet, Hardware Pack and Feet Packaging from the Drawer which marked with the rope.


NO	PARTS LIST		
A	Dresser		1
B	Front Right Feet		1
C	Front Left Feet		1
D	Rear Right Feet		1
E	Rear Left Feet		1
F	Support Leg		1



NO	HARDWARE LIST		
G	JCBC M6 x 35mm		8
H	Spring Washer		8
I	Washer $\varnothing\frac{1}{4}$ " x 20mm		8
J	Allen Key M4		1



"FR" & "FL" Marking at bottom of the Unit & top of the Leg



"BR" & "BL" Marking at bottom of the Unit & top of the Leg

STEP 2

Align & fasten feet (B),(C),(D) and (E) to Unit according to the position left and right follow the label correctly using bolt (G), lock washer (H) and flat washer (I) and fully tighten with Allen Key (J). Align and tighten Support Leg (F) with leveler to bottom panel of unit (A) by turning center feet with leveler clockwise until tight.