




ASSEMBLY INSTRUCTIONS

Customer Service : cs@nbrehome.com



Tools Recommended

THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.

Need Parts or Assistance? Email us : cs@nbrehome.com

IMPORTANT NOTICE

- This product contains small components, please ensure that they are kept away from small children.
- THIS INSTRUCTIONS CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ BEFORE ASSEMBLY AND KEEP FOR FUTURE REFERENCE.
- Read each step carefully. It is very important that each step of instruction is performed in the correct order. If these steps are not followed in sequence, assembly difficulties will occur.
- Make sure all parts are included. Most parts are labelled or stamped on the raw edge.
- Work in spacious area, preferably on a carpet, near the place the unit will be used.
- Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.
- Move your new furniture carefully, with two people lift and carry the unit to it's new location.
- Never push, drag or pull your furniture (especially on carpet)






PLEASE DO NOT RETURN PRODUCT TO US IMMEDIATELY

If a part is missing or damaged, email our customer service. We will gladly ship your replacement parts FREE of charge.

Need Parts or Assistance? Email us : cs@nbrehome.com

For Prompt, reliable service, please have your assemble instruction ready

 WARNING	
	<p>Children have died from furniture tipover. To reduce the risk of furniture tipover:</p> <ul style="list-style-type: none">- ALWAYS install Anti-tip device provided.- NEVER put a TV on this product.- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.- NEVER open more than one drawer at a time.- Place heaviest items in the lowest drawers.
	<p><i>This is a permanent label. Do not remove!</i></p>

Total number of boards required for this product: 74pcs

Includes frame plate: 17pcs









part 1*1pc part 2*1pc part 3*1pc part 4*1pc part 5*1pc part 6*1pc part 7*1pc
 part 8*1pc part 9*1pc part 10*2pcs part 11*1pc part 18*1pc part 19*1pc part 23*2pcs
 part 24*1pc

Includes feet: 1pc

part 25*1pc


Includes drawer board: 56pcs

part 12*10pcs part 13*10pcs part 14*6pcs part 15*6pcs part 16*6pcs part 17*6pcs part 20*4pcs
 part 21*4pcs part 22*4pcs




Step 1

Lock the guide rail (**CL**) to the part ② with the screw (**H**), then lock the guide rail (**CR**) to the part ③ with the screw (**H**). The installation position is as shown in the figure below.




Step 2

Lock screw (**A**) and foot pad (**D**) on the part ② and ③. The installation position is as shown in the figure below.




Step 3

First lock the guide rail (**CL**) to the right side of the part ②③ with the screw (**H**), then turn it 180 degrees and lock the guide rail (**CR**) to the left side of the part ②③ with the screw (**H**), the part ②③ total of 2 sets are required to be assemble, the installation position is as shown below.




Step 4

First lock the guide rail (**CL**) to the right side of the part ②④ with the screw (**H**), then turn it 180 degrees and lock the guide rail (**CR**) to the left side of the part ②④ with the screw (**H**), the installation position is as shown below.




Step 5

First lock the guide rail (**CL**) to the right side of the part ④ with the screw (**H**), then turn it 180 degrees and lock the guide rail (**CR**) to the left side of the part ④ with the screw (**H**), the installation position is as shown below.




Step 6


Lock screw (**A**) on the part ⑱ and ⑲.
The installation position is as shown in the figure below.





Step 7 Insert the dowel (C) into part 23 first, then assemble part 18, 19 and part 23, then use screw (E) to lock the part 18, 19 and part 23. The installation position is as shown below.





Step 8 Insert the dowel (M) into part 24 first, then assemble part 18, 19 and part 24, then use screw (E) to lock the part 18, 19 and part 24. The installation position is as shown below.



Step 9 Use screw (E) to lock the part ④ and part ⑨. The installation position is as shown below.




Step 10 Insert the dowel (M) into part ④ first, Then assemble parts ⑱, ⑲ and ④, put eccentric (B) into the corresponding hole, and tighten it with screw (A) by turning it clockwise with a screwdriver. The installation position is as shown below.




Step 11

Lock screw **(A)** on the part ⑥, ⑧ and ⑪, then use screw **(E)** through the part ⑦ to lock the part ⑫, then screw on adjustment foot pad **(L)** on part ⑭. The installation position is as shown in the figure below.




Step 12


Insert the dowel **(C)** into part ⑥ first, Then assemble parts ⑥ and ⑪, put eccentric **(B)** into the corresponding hole, and tighten it with screw **(A)** by turning it clockwise with a screwdriver. Lock foot pad **(D)** on the part ⑪. The installation position is as shown below.



Step 13




Assemble part ⑥, ⑦ and part ⑧, then put the eccentric (**B**) into the corresponding hole and use a screwdriver to turn it clockwise to tighten. The installation position is as shown below.




Step 14



Insert the dowel (**C**) into part ④ first, then assemble part ④, ⑥ and part ⑧, then use screw (**E**) to lock the part ④, ⑥ and part ⑧. The installation position is as shown below.



Step 17




Insert the dowel **(C)** into part **(3)** first, then assemble part **(5)**, **(6)**, **(8)**, **(9)**, **(11)**, **(18)**, **(19)**, and part **(3)**. Put the eccentric **(B)** into the corresponding hole and use a screwdriver to turn it clockwise to tighten. The installation position is as shown below.




Step 18

Insert the part ⑩ into the slots of the parts ② and ③. The installation position is as shown below.







Step 19 Lock screw (A) on the part ①.
The installation position is as shown in the figure below.



Step 20

Insert the dowel (C) into part ②, ③, ⑤, ②③ and ②④ first, then assemble part ②, ②, ③, ②③, ②④ and part ①. Put the eccentric (B) into the corresponding hole and use a screwdriver to turn it clockwise to tighten. Use screw (E) to lock the part ⑤ with the part ①. Rotate the foot pad (L) to enable it to support the product. The installation position is as shown below.





Step 21

Lock screw (A) on the part ⑰ and ⑳.

And then use hardware (J) to lock the handle (K) on the part ⑰ and ⑳.

The installation position is as shown in the figure below.




Step 22

Use screw (F) to lock the part ⑫, ⑬ and ⑳.



Use screw (F) to lock the part ⑫, ⑬, ⑭ and ⑮.

The installation position is as shown in the figure below.





Step 23

Insert the part ⑯ into the slots of the part ⑫ and ⑬.
Insert the part ㉒ into the slots of the part ⑫ and ⑬.
The installation position is as shown below.





Step 24 First use eccentric (B) to combine the part ⑫ and ⑬ with the part ㉐ respectively, and then use eccentric (B) to combine the part ⑫, ⑬ and ⑮ with the part ⑰ respectively.
The installation position is as shown below.




Step 25


Use screws (**H**) to install the guide rail (**DL**) on the side panel **(12)**, and install the guide rail (**DR**) on the side panel **(13)**. Drawer total of 10 sets are required to be assembled. The installation position is as shown in the figure below.



x4





x6








Step 26

Place the drawer into the corresponding position, as shown in the figure.






Step 27

Use the small screws in the hardware bag (**G**) to lock the piece of iron to the part ①. Lock the backplane buckle (**I**) to the four corners of the backplane. The following figure shows the installation position.



Step 28



First knock the expansion screws in hardware (**G**) into the wall with a hammer, and then use the long screws in hardware (**G**) to pass through the iron sheet and lock into the expansion screws in the wall. The following figure shows the installation position.

