

CARE AND MAINTENANCE







Wipe clean with a soft, dry cloth. Test the cleaning method on a hidden area before using them over the entire area.


NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finished product during assembly.
- * This item may require periodic tightening.
- * Do not tighten bolts until completely assembled.

Product Dimensions: 26-5/8"W x 30"D x 30"H

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Iron Base		1x
B	Seat Cushion		1x
C	Back Cushion		1x
HW1	Hex Socket Bolt	 1/4"-20 x 3/4"	4x
HW2	Hex Socket Bolt	 1/4"-20 x 1-1/4"	3x
HW3	Allen Key	 M4	1x




Weight capacity : 275 lbs
WARNING : DO NOT STAND ON THE PRODUCT
WARNING : DO NOT OVER TORQUE BOLTS

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 15 minutes.

Tools Required for Assembly (included): Allen Key




Step 1

Turn the Iron Base (A) upside down, Attach the underneath of Seat Cushion (B) to the Iron Base (A) and aligning screw holes. Using the Allen Key (HW3) to lock with 4*Hex Socket Bolts (HW1).



Step 2

Attach the back side of Back cushion (C) on the upper of Iron base (A) and aligning screw holes. Using the Allen Key (HW3) to lock with 3*Hex Socket Bolts (HW2)



Step 3

Straighten up the assembled product, Assembly is completed.