

# TILE INSTALLATION GUIDE

---

## INTRODUCTION

The following information is intended as an overview of the tile installation process. It is not meant as a step-by-step instruction manual, but rather as a way to familiarize yourself with the basic process. Carefully follow all instructions provided by the manufacturers of your setting materials to ensure success.

### TOOLS

Have the right tools and installation products before you begin your tile installation. Some of the supplies you may need are a wet saw, tile nippers, safety glasses, trowels, sponges, grout, tile spacers, thinset, gloves, a grout float, and a few buckets.

### SURFACE PREPARATION

Your installation surface or subfloor (if using floor-rated tile) must be sound, flat, solid, and clean of all debris.

### LAYOUT / DRY LAYING

Plan your layout by measuring carefully to minimize cuts, and dry lay your tiles for fit. Ensure that all of your tiles are marked as the same dye lot number. Additionally, it is beneficial to mix tiles from different cases to prevent any obvious shade variations.

### IMPORTANT TILE CUTTING INSTRUCTIONS

We recommend wet cutting or the score and snap method during installation process. Improper installation techniques could expose installer to inhalation of harmful silica dust.

Do not dry cut product using power tools during the installation process. Using dry cutting methods could present a risk of acute lung injury. If adequate ventilation cannot be achieved, wear a mask or respirator.

### THINSET AND MASTIC

Be sure to select the correct type of adhesive suitable for your installation. This can vary by tile material and installation location. There are a variety of adhesives available, such as mastic, thinset, polymer-modified thinset, and epoxy. Follow the instructions provided by the manufacturer of your chosen adhesive.

### LAYING THE TILES

Apply the thinset with an appropriately-sized notched trowel, then lay and press the tiles in place, using a rubber mallet if needed. Use spacers to create uniform grout lines.

### GROUT SELECTION

Sanded or non-sanded grout should be used, depending on the product you are installing. Floor tiles must be grouted. For grout lines of 1/8" and larger, sanded grout is more suitable. The sand in the grout mixture decreases the shrinkage as it cures, making it ideal for wider grout lines. Non-sanded grout is used for grout lines 1/8" and smaller. It's also best for mosaics and decorative tiles with delicate finishes, such as metallic pieces or high gloss products, as the texture of sanded grout can scratch them. Grout color is a matter of personal taste. Please note that grout colors have a drastic impact on the look of your installation. Whether you choose a complementing or contrasting color, be mindful that any selection may look different after drying.

### APPLYING GROUT

The setting material must be fully dry before attempting to grout. Consult the instructions for your setting material to find the recommended drying time. Apply grout in small sections using a rubber float. Pull the grout across the surface, pushing it fully into the grout lines and keeping excess from building up on the tile surface. Keep the grout level, without any pits or low spots.

### GROUT CLEANUP

With a dry, lint-free cloth, remove excess grout from the surface of the tile. Lightly dampen a sponge with warm water and continue to clean grout off of the tile. Once it appears to be clean, wipe it down again with a fresh, lightly damp sponge to remove any grout film. After about 15 minutes, buff the tile with a soft cloth. Finished grout should be smooth, uniform in color, and have no visible holes, pits, or uneven height issues.

## SPECIAL NOTES FOR MOSAIC TILES

### MESH BACKING

Have the right tools and installation products before you begin your tile installation. Some of the supplies you may need are a wet saw, tile nippers, safety glasses, trowels, sponges, grout, tile spacers, thinset, gloves, a grout float, and a few buckets.

### STAINLESS STEEL AND ALUMINUM MOSAICS

You can prevent scratches on these surfaces by using a clean sponge, keeping the protective cover on and applying non-sanded grout during installation. If necessary, cut this tile from the rear with a diamond-tipped wet saw to prevent uneven edges. Cut edges can then be treated and smoothed with fine sandpaper or a metal file.