

SLAT KIT FULL BED

ASSEMBLY INSTRUCTION


(FULL)

Before assembling your bed slat kit, please read through these instructions carefully and familiarize yourself with the different parts. Please note that you will require a Phillips head screwdriver and an allen wrench.

ATTENTION! If you receive a damaged or defective item, please contact service



PARTS LIST





PO :

01	SLAT SECTION	2 SET
02	CENTER RAIL	2 PCS
03	TALL SUPPORT LEG	4 PCS
04	SHORT SUPPORT LEG	4 PCS

HARDWARE

NOTE: WE INCLUDE SPARE HARDWARE IN CASE THE ALLEN WRENCH, ALLEN SCREW OR WOOD SCREW ARE DAMAGED DURING ASSEMBLY.



Step 1




Assemble bed frame according to bed assembly instructions.

If using mattress and foundation set the bed up low and use short support leg.

If using Storage Drawers or Trundle Bed choose the tall support leg.

Step 2

Assemble support leg (03 / 04) and center rail (02).
Using Allen screw (A).
Tighten with the Allen wrench (C).
Repeat for other center rail.



SLAT KIT FULL BED

Step 3

Lay the slat kit (01) onto the bed.
Attach center rail (02) to slat kit (01).
Using Allen screw (A), tighten with the Allen wrench (C).
Repeat for section 2.



Adult assembly

A





1 1/2" Allen screw

C



Allen wrench




Step 4



Adult assembly

B




1 1/4" Wood screw



Phillips head
screwdriver

Customer supplied



Be sure to align slat kit evenly with both ends of ledger strip.

Screw slat kit (01) to side rail, using wood screw (B).
Tighten with Phillips head screwdriver.
Be sure the space between slats is even.