


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench



(Included)

Wrench



(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.












FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.













Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.

Parts List

	#1 x 1 pc Headboard
	#2R x 1 pc Right H/Board Leg
	#2L x 1 pc Left H/Board Leg
	#3 x 1 pc Leg Support
	#4 x 1 pc Footboard
	#5 x 2 pcs Side Rail
	#6 x 4 pcs Slat
	#7 x 8 pcs Slat Support Leg 40x40x148mm
	#K x 4 pcs Dowel


Hardware List

	#A x 2 pcs Bolt 1/4" X 1-5/8"
	#B x 6 pcs Bolt 1/4" x 2"
	#C x 8 pcs Lock Washer
	#D x 8 pcs Flat Washer
	#E x 1 pc Allen Wrench
	#F x 8 pcs Threaded Stud 5/16" X 4"L
	#G x 8 pcs Hex Nut
	#H x 8 pcs Beveled Washer
	#I x 1 pc Wrench
	#J x 8 pcs Screw 1-1/4"



Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.



Note : Left and right is determined by facing the front of the headboard in its upright position.

#A x 2 pcs
#C x 4 pcs
#D x 4 pcs
#K x 4 pcs


1. Insert 2 dowels (#K) into each end of the leg support (#3), then insert the other ends into the left and right headboard leg (#2).




2. Insert a bolt (#A) with lock washer (#C) and flat washer (#D) into the inner holes. Secure using the Allen wrench (#E).



#B x 6 pcs
#C x 6 pcs
#D x 6 pcs




1. Align the headboard (#1) to the holes along the top of the headboard legs (#2)




2. Insert 3 bolt (#B) with lock washer (#C) and flat washer (#D) into the holes along each leg. Secure using the Allen wrench (#E).



#F x 8 pcs
#G x 8 pcs
#H x 8 pcs




1. Insert the threaded studs (#F) into the holes along the headboard legs (#2), then place each end of the side rails (#5) onto those studs.



2. Apply a beveled washer (#H) then a hex nut (#G) onto each stud from within the rails. Secure using the wrench.



X4





Insert the threaded ends of the slat support legs (#7) into the holes along the slats (#6), turn right to tighten.



#J x 8 pcs

Place the slats (#6) onto the side rails (#5), then insert a screw (#j) into each end. Secure using a screwdriver.





ASSEMBLY IS COMPLETED