


ASSEMBLY INSTRUCTIONS



Fine Furniture for every stage of life

Day Bed

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.








ASSEMBLY TIME




30 MINUTES

PARTS IDENTIFICATION






B1 (BOX 1)

A	RIGHT SIDE PANEL		1PC	D	BUN FOOT		4PCS
B	LEFT SIDE PANEL		1PC	E	ROLL SLAT (13PCS)		1SET
C	FINIAL		4PCS				

B2 (BOX 2)

F	BACK PANEL		1PC	H	BACK RAIL		1PC
G	FRONT RAIL		1PC				

B3 (BOX 3)

I	TRUNDLE ROLL SLAT (13PCS)		1SET	L	TRUNDLE RIGHT SIDE PANEL WITH CASTER		1PC
J	TRUNDLE FRONT PANEL		1PC	M	TRUNDLE LEFT SIDE PANEL WITH CASTER		1PC
K	TRUNDLE BACK PANEL		1PC				

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.








WARNING!









1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2 (BOX2) - HARDWARE PACK IS LOCATED

1	BOLT (1/4 x 110mm Φ 15L4 - RBW)		12PCS	4	WOOD DOWEL (10 x 40mm)		8PCS
2	HALF ROUND NUT (1/4 x 22mm - RBW)		12PCS	5	ALLEN WRENCH (4 x 57MM - RBW)		1PC
3	FLAT HEAD SREW (4 x 30mm - RBW)		26PCS				

Z-B3 (BOX3) - HARDWARE PACK IS LOCATED


6	LONG BOLT (1/4 x 50mm Φ 12L4 - RBW)		2PCS	10	WOOD DOWEL (10 x 40mm)		4PCS
7	HALF ROUND NUT (1/4 x 22mm - RBW)		2PCS	11	KNOB (5/32mm - RBW)		4PCS
8	SHORT BOLT (1/4 x 35mm Φ 12L4 - RBW)		4PCS	12	BOLT WITH WASHER (1/4 x 20mm Φ 12L4 - RBW)		4PCS
9	FLAT HEAD SCREW (4 x 30mm - RBW)		26PCS	13	ALLEN WRENCH (4 x 57MM - RBW)		1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4





ASSEMBLY INSTRUCTIONS


STEP 5



STEP 6 COMPLETE



Inner Size: 80.00"W x 40.00"D
Trundle Inner Size: 75.25"W x 40.00"D



Note: Dimension tolerance $\pm 5\%$