


ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning !!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

(A) LEFT SIDE PANEL




1 PC

(C) TOP/BASE



2 PCS

(B) RIGHT SIDE PANEL



1 PC

(D) SHELF




4 PCS

HARDWARE IDENTIFICATION


1	BIG SELF-TAPPING SCREW	Φ 4x35mm		20pcs
2	DOWEL	Φ 8x25mm		14pcs
3	SPONGES PAD	Φ 22x3mm		1pc
4	THE RESTRAINT STRAP	197×5×1mm		1pc
5	BRACKET	12×12×1mm		2pcs
6	SMALL SCREW	Φ 4x25mm		1pc
7	WALL SCREW	Φ 5x40mm		1pc
8	PLASTIC ANCHOR	Φ 8x40mm		1pc
9	GLUE			1pc

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4



ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT


WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture may result in injury and damage.

This tip restraint must be attached to a wall stud using long screw enclosed.


STEP 1

Attach a bracket securely to the back top rail to the furniture using short screw provided, through the smaller hole.



STEP 2

Locate the other bracket on the wall over a wall stud and two inches below the mounting bracket secured to the back of the furniture. Attach the wall stud using the long screw provided, through the smaller hole.



STEP 3

Place the restraint into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide them, a flat end through the locking and draw it until all slack is removed. Confirm that the strap is securely laced and locked.

