

---

# J3M025KH02A




As this item contains many parts, please read the installation instruction carefully before installation . Please use tools properly and carefully. If you have any questions about the product and installation, please contact us.

**[hosoteservice@gmail.com](mailto:hosoteservice@gmail.com)**

Our professional after-sales team will serve you online all day.

---

# Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

# Helpful Hints

## PEOPLE NEEDED FOR ASSEMBLY: 1-2


- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.
- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.




---

# Board Identification


Not actual size




Ⓐ  
DESK TOP




Ⓑ  
LEFT SIDE PANEL




Ⓒ  
LEFT SIDE PARTITION




Ⓓ  
RIGHT SIDE PARTITION




Ⓔ  
RIGHT SIDE PANEL




Ⓕ  
LEG



Ⓖ  
LEG



Ⓗ  
LEG




Ⓘ  
LEG

---


# Board Identification

Not actual size




(J)

FRONT SLAT  
Qty:2




(K)

FRONT SLAT




(L)

BACK SLAT




(M)

LEFT SIDE BOTTOM



(N)

RIGHT SIDE BOTTOM




(O)

SHELF PANEL




(P)

LEG  
Qty:2



(Q)

DOOR




(R)

DRAWER FRONT PANEL

---


# Board Identification

Not actual size




Ⓢ

DRAWER FRONT PANEL




Ⓣ

DRAWER FRONT PANEL




Ⓤ

DRAWER FRONT PANEL




Ⓥ

DRAWER FRONT PANEL




Ⓦ

DRAWER LEFT SIDE PANEL  
Qty:3




Ⓧ

DRAWER RIGHT SIDE PANEL  
Qty:3




Ⓨ

DRAWER LEFT SIDE PANEL



Ⓩ

DRAWER RIGHT SIDE PANEL




ⒶⒶ

DRAWER LEFT SIDE PANEL

---


# Board Identification

Not actual size




ⓑ

DRAWER RIGHT SIDE PANEL




ⓒ

DRAWER BACK PANEL




ⓓ

DRAWER BACK PANEL  
Qty:2




ⓔ

DRAWER BACK PANEL




ⓕ

DRAWER BACK PANEL




ⓖ

DRAWER BOTTOM PANEL




ⓓⓓ

DRAWER BOTTOM PANEL  
Qty:3



ⓓⓓ

DRAWER BOTTOM PANEL




ⓓⓓ

DRAWER BOTTOM SLAT

---


# Board Identification

Not actual size



ⓀⓀ

BACK PANEL




ⓁⓁ


BACK PANEL

# Board Identification


Not actual size




# Part List




CAM LOCK  
spare: 3




CAM BOLT  
spare: 3




WOOD DOWEL  
spare: 3




SCREW  
spare: 2




SCREW  
spare: 5




SCREW  
spare: 1




SCREW  
spare: 1




HANDLE




SCREW  
spare: 1




SCREW  
spare: 1




LEFT CABINET MEMBER




RIGHT CABINET MEMBER




LEFT DRAWER RUNNER



RIGHT DRAWER RUNNER







SCREW  
spare: 2




SHEIF SUPPORT  
spare: 1

# Part List















## Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.














# STEP 1




Proper orientation of CAM LOCK

# STEP 2













Proper orientation of CAM LOCK

# STEP 3








# STEP 4








Proper orientation of CAM LOCK













# STEP 5









# STEP 6



# STEP 7











# STEP 8



Proper orientation of CAM LOCK


# STEP9



Please make sure that the screw is VERTICAL so as not to affect the sliding of the drawer.







# STEP 11







Please make sure that the screw is VERTICAL so as not to affect the sliding of the drawer.

# STEP12









# STEP13

---







# STEP14









Proper orientation of CAM LOCK

# STEP15







# STEP 16







Proper orientation of CAM LOCK

# STEP17










Before attaching the back panel, be sure that the unit is at 90°  
Avant d'attacher le panneau arrière, assurez-vous que l'unité est à 90°  
Antes de fijar el panel posterior, asegúrese de que la unidad esté a 90°

# STEP18






# STEP19




# STEP20


---



**Step 1**  
Select the desired height  
and put it in






**Step 2**  
Aim the board gaps down





# STEP21

---





## To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



## To adjust depth.

Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".



## To adjust side ways.

Turning the screw "C" on BOTH hinges on each door.