


# Installation & Assembly



Wood Lift Coffee Table



## IMPORTANT INFORMATION

READ CAREFULLY.

KEEP THIS INFORMATION FOR FURTHER REFERENCE.

### GENERAL GUIDELINES


- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please **contact us** when further information and help are needed.

### NOTES

- Please follow the assembly instructions precisely and only use the product as intended.
- If an odor is present when first opening the package, please leave the unwrapped product in a shaded and ventilated area for a few days to air out.
- Prior to assembly, please check the product for defects or missing accessories. If any defects are found or accessories are missing, do not use product as damage or injury may occur;  
Please **contact us** for assistance and replacement.
- During assembly, please only slightly tighten all screws in their correct position first, then fully tighten them. A Philips screwdriver is recommended but not included.
- It is suggested you regularly check the products bolts and connections to ensure safe use.
- Assemble the item on a soft flat and clean surface to avoid scratches and damage.
- It is recommended that two people assemble this product.

### WARNINGS

- During assembly, keep parts and packaging materials away from children and pets as there could cause injury and are a potential choking hazard.
- Avoid sharp objects or corrosive chemicals to prevent damage to the product.
- Please open the item slowly and cautiously to avoid pinching your hands by metal joints, especially children.




- If you have any further questions, please feel free to contact us




We will reply ASAP.

- Before installation, please make sure you have all the hardware, the serial numbers are properly labeled corresponding to the list, and the quantity is correct.
- Enjoy your new purchase!

# EXPLODED DRAWING






## PARTS





|                                                                                                  |                                                                                                  |                                                                                                            |                                                                                                            |
|--------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
|  <b>A</b> X36 |  <b>B</b> X20 |  <b>C</b> X36           |  <b>D</b> X1          |
|  <b>E</b> X1  |  <b>F</b> X22 |  <b>G</b> X36<br>M4x14 |  <b>H</b> X7<br>M6x23 |
|  <b>I</b> X2  |  <b>J</b> X1  |  <b>L</b> X1           |  <b>M</b> X8          |



## REMARK

### MINIFIX POSITION





1










**REMARK**


Please do not screw **A** too deep or too shallow.


**x2**









|                                                                                     |             |
|-------------------------------------------------------------------------------------|-------------|
|  | <b>A</b> X2 |
|  | <b>B</b> X4 |













|                                                                                     |              |
|-------------------------------------------------------------------------------------|--------------|
|  | <b>A</b> X10 |
|  | <b>B</b> X4  |







×2




















origin wood - colored





pure colored



**REMARK**



Please wait for 3 minutes until it glues completely.








## REMARK

Fully tighten all the screws after all the screws are in right place.



## REMARK


Push the 10-gauge boards from the both sides into the groove of the 13-gauge board.




**G** x8


|                                                                                    |             |                                                                                     |             |
|------------------------------------------------------------------------------------|-------------|-------------------------------------------------------------------------------------|-------------|
|  | <b>H</b> X5 |  | <b>L</b> X1 |
|                                                                                    | M6x23       |                                                                                     |             |

**REMARK**


Fully tighten all the screws after all the screws are in right place.




|                                                                                               |                                                                                                |                                                                                                           |
|-----------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
|  <b>D</b> X1 |  <b>E</b> X1 |  <b>G</b> X12<br>M4x14 |
|-----------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|

**REMARK**

Fully tighten all the screws after all the screws are in right place.





|                                                                                    |             |                                                                                     |             |
|------------------------------------------------------------------------------------|-------------|-------------------------------------------------------------------------------------|-------------|
|  | <b>H</b> X2 |  | <b>L</b> X1 |
|                                                                                    | M6x23       |                                                                                     |             |



**REMARK**

Fully tighten all the screws after all the screws are in right place.

**G** ×16

**F** x22