

BOX SPRING


Set-up Instruction

BS:01/02


Size: Twin/Twin XL

If you have any questions about the product, please don't hesitate to contact us. You can reach us through your order. Thanks for your support!

Package Parts List



A*2PCS




B*2PCS



B1*2PCS




G*1PCS



J*4PCS



H*10PCS



D*1pcs
(Bed cover)

Accessories List




T*2pcs
M6*35 (bolt)



L*8pcs
M6*20 (bolt)




P*10pcs
M6*8 (bolt)




Z*1pcs



Step1:



B1*2PCS A*2PCS




L*4pcs
M6*23 (bolt)




L



Step2:




B*2PCS





P*2pcs
M6*8 (bolt)







P







Step3:





Step4:



Step5:





Step6:



Step7:

(Put on the fabric bedcover)



Please open the bed cover and distinguish the length and width first before use it, and make sure it will cover the box spring perfect.