



# Coat Hooks






Thank you for purchasing our Coat Hooks. Assembly of this product requires a screwdriver. **We have found it helpful to have a second person present in at least one step of the assembly.**

## Coat Hooks Assembly Instructions

Lay out all parts on a "non-abrasive" surface to avoid scratching furniture.



NO.	DRAWING	DESCRIPTION	Q'TY
A		HOOK PLATE	1
B		FRENCH CLEAT	1
C		WOOD SCREW 4*50	4

### PARTS

#### Step 1

Read through these instructions thoroughly before beginning assembly. We have found this to be of great value when first assembling this product.


## Step 2

Remove all parts and hardware from packing material. Wooden pieces should be placed on a non abrasive surface (like the carton or carpet) to prevent damage to the finish. Note the French Cleat (B) is pre-installed on the back of the Hook Plate (A) with 3 of the Wood Screws (C).

---

## Step 3


Remove the French Cleat (B) from the back of the Hook Plate (A) by unscrewing 3 of the pre-installed Wood Screws (C) on the top of the Hook Plate (B). Locate studs behind drywall in desired location. Attach French Cleat (B) to wall studs with 2 Wood Screws (C).



---

## Step 4


Set Hooks Plate (A) on French Cleat (B).



---

## Step 7

Attach Hook Plate (A) to French Cleat (B) with 3 Wood Screws (C).



---

## CARE

Clean with mild soap and wipe dry.

---

## REPLACEMENT PARTS

Please do not contact the company you purchased from as we can help you faster.

Order replacement parts and hardware at our website.