















Mission Oak Corner Mantel Height Bookcase with Drawer



Hardware List

Item		Description	Qty
a		Bolt 1/4"x1-1/8"	8PCS
b		Flat Washer 1/4"x16mm	8PCS
c		Allen Wrench	1PC
d		Shelf Metal Clip	8PCS
e		Black Screw	2PCS

Parts List


	Item	Description	Qty
A		Top	1PC
B		Left Front Frame	1PC
C		Right Front Frame	1PC
D		Left Back Panel	1PC
E		Right Back Panel	1PC
F		Back Panel	1PC
G		Shelf Panel	2PCS
H		Bottom Panel	1PC

Assembly Instructions

Two person assembly recommended.


step 1

Insert left back panel (D) into left front frame (B) as per following sketch, push the left back panel down until flush to make it tight. Do the same assembly step on right back panel (E) and right front frame (C).




step 2

Place left side frame (D & B) upside down onto top assembly. Make sure the wooden dowels on left side frame go into the top holes first. Fasten the side frame and top with bolts when the front side frame rail is flush with drawer front.




step 3

Open the back panel (F) and insert it into left side frame groove, place the right side frame on the top and the groove into the back panel. Tighten the bolts when the front side frame rail is flush with drawer front.



step 4

Place the bottom shelf (H) inside and make sure the back panel goes into the bottom shelf groove. Fasten the bottom shelf with four bolts, tighten all bolts when the shelf front rail is flush with the side frames.



Two person assembly recommended.

Place the bookcase right side up and fasten the back panel with two screws.



Furniture Tipping Restraint

Wall

A

G

G

FRONT

FRONT

d

Top

Wall

Furniture Tipping Restraint must always be used to prevent serious harm or death to children.