


TV Stand

Assembly Instructions - Please keep for future reference



Dimensions

Width-70.87 inch

Depth-14.96 inch

Height-22.05 inch

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure That all bolts and fittings are tightend properly.

WARNING
In order to help prevent overturning –
please follow these instructions

To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.











4



Assembly Instructions















Assembly Instructions

			
1800x380x15mm	380x360x15mm	380x360x15mm	380x360x15mm
① x 1	② x 1	③ x 1	④ x 1
			
886x390x3mm	1800x360x15mm	874.5x334x12mm	216x70x15mm
⑤ x 2	⑥ x 1	⑦ x 2	⑧ x 2
			
1520x70x15mm	448x392x18mm	448x392x18mm	
⑨ x 2	⑩ x 3	⑪ x 1	Hardware Pack X1


Components-Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

(A)  Cam Bolt x 18+2	(B)  Cam Bolt x 16+2	(C)  Cam Lock x 34+2	(D)  8*30mm Dowel x 16+2
(E)  5*40mm Screw x 6+1	(F)  Shelf support pin x 8+1	(G) Half Overlay Hinge Package Color: Red  Hinge x 4	(H) Full Overlay Hinge  Handle x 4
(J)  Rebound device x 4	(K)  Iron Sheet x 1	(L)  Back panel buckle x 12+2	(M)  3.5*12mm Screw x 72+3
(N)  felt x 5+1	(O)  Hole to stick x 6+1	(P)  150*40*40Leg x 4	(R)  143*40*40Leg x 1
(S)  Anti dumping x 2 set	 Screwdriver x 1		


Step 1



A*6




J*4



M*8




Step 2



A*12




K*1



M*4




Step 3



D*12




Step 4




C*6



Step 5




Step 6



E*6




Step 7



Step X4

B*16




D*4



P*4



Step 8




C*8




Step X2

Step 9




C*8




Step 10

It's better if two people work together on this step.


Please flip carefully!



C*12




Step 11



R*1




Step 12



N*5



Step 13



As the picture shows,
Fix hardware "L" into the gap with screws
to make the back panel more stable.

L*12




M*12



Step 14


It's better if two people work together on this step.

Please flip carefully!



Step 15


Please stick the hardware "O" on the exposed cam lock hole that makes your product more beautiful.



O*6



Step 16




F*8







The shelf can be adjusted up and down

Step 17

Please carefully distinguish between G and H hinges during the installation steps and adhere strictly to the instructions in their prescribed order to avoid any installation errors.




Note: The packaging bag features red marking to easily distinguish between the two types of hinges. (G : Red)







Step 18

Please carefully distinguish between G and H hinges during the installation steps and adhere strictly to the instructions in their prescribed order to avoid any installation errors.




Note: The packaging bag features red marking to easily distinguish between the two types of hinges. (G : Red)







Step 19

Please carefully distinguish between G and H hinges during the installation steps and adhere strictly to the instructions in their prescribed order to avoid any installation errors.




Note: The packaging bag features red marking to easily distinguish between the two types of hinges. (G : Red)







Step 20


Please carefully distinguish between G and H hinges during the installation steps and adhere strictly to the instructions in their prescribed order to avoid any installation errors.




Note: The packaging bag features red marking to easily distinguish between the two types of hinges. (G : Red)



Step 21





When the hinges are installed, you can refer to the pictures to adjust crevice of the doors till it's perfect:




1. To adjust the doors up and down, please refer to step (a)
2. To adjust the distance between the doors and side panels, please refer to step(b)
3. To adjust the gap between two doors, please refer to step (c)
4. After the adjustment finished, please tight the screws, refer to step (d)

Step 22




OR

This is anti-dumping L-type iron sheet, fixed to the wall of the product, can be required to change the installation location



S*2



Step 23

FINISH

