





Wine cabinet






IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.






AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer- could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !

Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.


'SAFETY TIPS:

Static charge may cause dust on foam- clean with a dry or damp cloth.
Smafoam strands may represent - handle gently and dispose of properly.


Do not burn or incinerate.

Check local recycling guidelines.


Board Identification




PARTS LIST




①




②



③




④




⑤




⑥




⑦




⑧ x 2




⑨ x 2



⑩




⑪




⑫



⑬ x 2




⑭




⑮




⑯ x 2




⑰




⑱




⑲





⑳



㉑










Please prepare the following tools








When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size





<p>A x 62</p> <p>Ø 7 x 40 mm</p>	<p>B x 62</p> <p>Ø 15 x 9.5 mm</p>	<p>C x 66</p>	<p>D x 70</p> <p>Ø 6 x 30 mm</p>	<p>E x 9</p> <p>Ø 5 x 38 mm</p>
<p>F x 6</p> <p>Ø 5 x 50 mm</p>	<p>H x 2</p>	<p>J x 4</p>	<p>K x 4</p> <p>Ø 6 x 20 mm</p>	<p>L x 4</p> <p>Ø 6 x 30 mm</p>
<p>M x 20</p> <p>Ø 4 x 12 mm</p>	<p>W x 1</p>		<p>P x 4</p>	<p>Q x 2</p>
<p>S x 6</p>	<p>X x 4</p>	<p>U x 5</p>	<p>V x 11</p> <p>Ø 3.5 x 12 mm</p>	<p>LED x 1</p>
<p>O x 2</p>	<p>+ 2</p> <p>SPARE BAG</p>			





1

D x 2  Ø 6 x 30 mm	E x 1  Ø 5 x 38 mm	U x 4 	V x 4  Ø 3.5 x 12 mm	M x 12  Ø 4 x 12 mm	P x 4 	LED x 1 
---	---	--	---	--	--	--




2




D x 2  Ø 6 x 30 mm	E x 2  Ø 5 x 38 mm	A x 18  Ø 7 x 40 mm	
---	---	--	---








x 2










3

D x 12  Ø 6 x 30 mm	B x 18  Ø 15 x 9.5 mm	
--	--	---













4

U x 1 	V x 1  Ø 3.5 x 12 mm	A x 8  Ø 7 x 40 mm	
--	---	---	---







5

<p>A x 8</p>  <p>Ø 7 x 40 mm</p>	<p>B x 8</p>  <p>Ø 15 x 9.5 mm</p>	<p>D x 8</p>  <p>Ø 6 x 30 mm</p>	<p>M x 2</p>  <p>Ø 4 x 12 mm</p>	<p>O x 2</p> 	
---	---	---	---	--	---








6

<p>D x 6</p>  <p>Ø 6 x 30 mm</p>	<p>F x 6</p>  <p>Ø 5 x 50 mm</p>	
---	---	---










7

A x 12  Ø 7 x 40 mm	D x 4  Ø 6 x 30 mm	 +
--	---	--












8

<p>B x 10</p>  <p>Ø 15 x 9.5 mm</p>	<p>D x 8</p>  <p>Ø 6 x 30 mm</p>	
--	---	---










9

<p>K x 4</p>  <p>Ø 6 x 20 mm</p>	<p>B x 2</p>  <p>Ø 15 x 9.5 mm</p>	<p>D x 2</p>  <p>Ø 6 x 30 mm</p>	<p>W x 1</p> 	
---	---	---	---	---








10

A x 8  Ø 7 x 40 mm	D x 8  Ø 6 x 30 mm	E x 6  Ø 5 x 38 mm	
---	---	---	---





11


<p>A x 8</p>  <p>Ø 7 x 40 mm</p>	<p>B x 8</p>  <p>Ø 15 x 9.5 mm</p>	<p>X x 4</p> 	
---	---	--	---





x 4





x 2






12


<p>B x 8</p>  <p>Ø 15 x 9.5 mm</p>	<p>D x 8</p>  <p>Ø 6 x 30 mm</p>	
---	---	---




13





14



15

M x 2

Ø 4 x 12 mm



16

<p>B x 8</p>  <p>Ø 15 x 9.5 mm</p>	<p>D x 10</p>  <p>Ø 6 x 30 mm</p>	
---	--	---









Diagram A shows a screw being inserted into a hole in a wooden panel. Diagram B shows a screw being inserted into a hole in a wooden panel. Diagram B shows a screw being inserted into a hole in a wooden panel. A warning icon is also present.






17

<p>S x 6</p> 	<p>V x 6</p>  <p>Ø 3.5 x 12 mm</p>	 
--	---	---




18





A solid wall	B cavity wall	C solid wood
$\Phi 6\text{mm}$ (1/4")	$\Phi 6\text{mm}$ (1/4")	$\Phi 3\text{mm}$ (1/8")

! Warning: If you overturn the furniture, it may cause serious or fatal crushing injuries. We have a wall connection device attached, please use it to hold the furniture following these instructions.




1. Mark the corresponding hole positions where you want to place the furniture;
2. Use a impact drill to drill holes and pay attention to avoid wires and water pipes;
3. Knock the expansion pipes into the wall holes;
4. Place the furniture in the corresponding position and tighten the wall connection device with screws.




19



21




Use the stickers C to cover the holes




22




-LED lamp with effective remote control distance of 5 meters



1. Take out the remote control gasket



2. Align remote controller to the RGB Control box to adjust the color mode



- Installation complete.