







# ASSEMBLY INSTRUCTIONS



# WARNING!





























Assemble the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.  
Make sure no parts are missing or damaged before assembly.


















Not actual size

 <p>1 1PC</p>	 <p>2 1PC</p>	 <p>3 1PC</p>	 <p>4 1PC</p>	
 <p>5 2PCS</p>	 <p>6 1PC</p>	 <p>7 1PC</p>	 <p>8 1PC</p>	
 <p>9 1PC</p>	 <p>10 2PCS</p>	 <p>11 1PC</p>	 <p>12 2PCS</p>	 <p>13 1PC</p>
 <p>14 1PC</p>	 <p>15 1PC</p>	 <p>16 1PC</p>	 <p>17 1PC</p>	 <p>18 1PC</p>
 <p>19 1PC</p>	 <p>20 1PC</p>	 <p>21 1PC</p>	 <p>22 3PCS</p>	
 <p>23 3PCS</p>	 <p>24 3PCS</p>	 <p>25 3PCS</p>	 <p>26 3PCS</p>	

# PACKAGE CONTENT







# HARDWARE PART LIST





<p><b>A</b> X62+2</p>  <p>Ø6x34mm</p>	<p><b>B</b> X62+2</p>  <p>Ø15x9.5mm</p>	<p><b>C</b> X27+1</p>  <p>Ø6x30mm</p>	<p><b>D</b> X56+2</p>  <p>Ø6.5x12mm</p>
<p><b>E</b> X25+1</p>  <p>Ø8*35mm</p>	<p><b>F</b> X4</p>  <p>Ø3x15mm</p>	<p><b>G</b> X4</p> 	<p><b>H</b> X6</p> 
<p><b>I</b> X4</p> 	<p><b>J</b> X8</p>  <p>Ø5/23"x16mm</p>	<p><b>K</b> X1</p> 	<p><b>L</b> X1SET</p>  <p>L1 L2</p>
<p><b>M</b> X6</p>  <p>Ø13x4mm</p>	<p><b>N</b> X1</p> 	<p><b>O</b> X4SET</p>  <p>CL DL CR DR</p> <p>L300mm</p>	<p><b>P</b> X1SET</p>  <p>10PCS 1PC</p>
<p><b>Q</b> X1</p> 			

## Cam Lock Fastening System




Insert the cam bolt into the hole first, then insert the cam lock and lock it.




# STEP 1



# STEP 2







Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK






# STEP 3




Insert the cam bolt into the hole first, then insert the cam lock and lock it.







# STEP 4




Insert the cam bolt into the hole first, then insert the cam lock and lock it.






# STEP 5






# STEP 6




# STEP 7



# STEP 8




# STEP 9




(C)	X3
Ø6*30mm	

(E)	X7
Ø8*35mm	





# STEP 10





(A)	X6
Ø6x34mm	


(M)	X2
Ø13x4mm	




# STEP 11





ⓓ	X3
	
Ø6.5x12mm	


ⓐ	X1
	
L=300	





# STEP 12




Ⓐ	X7
	
Ø6x34mm	

Ⓜ	X2
	
Ø13x4mm	




# STEP 13




(D)	X9
Ø6.5x12mm	

(O)	X3
L=300	




# STEP 14





(A)	X7
Ø6x34mm	


(M)	X2
Ø13x4mm	




# STEP 15





(D)	X9
	
Ø6.5x12mm	


(O)	X3
	
L=300	




# STEP 16






(A)	X6
	
Ø6x34mm	




# STEP 17



(D)	X3
	
Ø6.5x12mm	

(O)	X1
	
L=300	





# STEP 18


(A)	X2
	
Ø6x34mm	





# STEP 19

<b>B</b>	<b>X2</b>
	
Ø15x9.5mm	


<b>C</b>	<b>X1</b>
	
Ø6*30mm	





Insert the cam bolt into the hole first, then insert the cam lock and lock it.





# STEP 20

<b>B</b>	<b>X7</b>
	
Ø15x9.5mm	





<b>C</b>	<b>X2</b>
	
Ø6*30mm	




Insert the cam bolt into the hole first, then insert the cam lock and lock it.




# STEP 21






Insert the cam bolt into the hole first, then insert the cam lock and lock it.





# STEP 22






# STEP 23





Insert the cam bolt into the hole first, then insert the cam lock and lock it.







# STEP 24




Insert the cam bolt into the hole first, then insert the cam lock and lock it.



# STEP 25





Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK

# STEP 26





ⓓ	X2
	
Ø6.5x12mm	


Ⓚ	X1
	




# STEP 27





ⓓ	X2
	
Ø6.5x12mm	


Ⓚ	X1
	





# STEP 28


(F)	X4
	
Ø3x15mm	




(G)	X4
	

(L1)	X1
	





# STEP 29


(A)	X18
	
Ø6x34mm	




# STEP 30





(E)	X16
	
Ø8*35mm	







# STEP 31




(E)	X2
	
Ø8*35mm	







# STEP 32







Insert the cam bolt into the hole first, then insert the cam lock and lock it.






# STEP 33





# STEP 34




# STEP 35



# STEP 36

<b>(P)</b>	<b>X1 set</b>
	10PCS
	1PC




Tear off a layer of 3M polyethylene foam.


# STEP 37

Pass the bulb wire through the pre punched plate, then gently press the bulb and make it adhere to the plate, and then connect the adjacent bulbs successively through the wire head slot on the opposite (corresponding to the line of the same color)


When connecting the interface, please note that the colors of the wires at both ends correspond one by one.




# STEP 38




## Install the tipping restraint hard ware




1. make mark on the wall




2. drill two  $\varnothing 6$  holes on the wall




3. put two anchors in the holes



4. fix the device on the wall by the long screws



5. Push the cabinet close to the wall so that the two bases are close to each other, and then put on nylon tie to tighten it.



# FURNITURE CARE AND MAINTENANCE

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



## MAINTENANCE

Tighten all bolts and screws again within the first 2 weeks of assembly  
Check the tightness of all bolts every 2 months, tighten them if necessary



## CLEANING

Clean the surface of the MDF and PB (medium - density fiberboard) with a lightly dampened cloth.

Small amount of mild soap can be used if necessary

- Dry the surface immediately after cleaning.

⚠ DO NOT use bleach or alcohol detergent to clean the surface.

⚠ DO NOT apply wood treatment on parts made with MDF/PB.

Medium - density fiberboard and PB will swell and distort when suffer from water damage.  
Make sure to dry the furniture immediately after cleaning