





















Hall Tree



PART LIST


A 	B 	C 	D 	E 
Top Panel 1 PC	Upper Left Side Panel 1 PC	Upper Right Side Panel 1 PC	Shelf 1 PC	Upper Vertical Panel 1 PC
F 	G 	H 	I 	J 
Back Upper Rail 1 PC	Back Bottom Rail 1 PC	Back Partition Rail 1 PC	Upper Back Panel 1 PC	Middle Back Panel 2 PCS
K 	L 	M 	N 	O 
Seat Panel 1 PC	Bottom Panel 1 PC	Lower Left Side Panel 1 PC	Lower Right Side Panel 1 PC	Middle Vertical Panel 1 PC
P 	Q 	R 	S 	T 
Adjustable Shelf 2 PCS	Bottom Back Panel 1 PC	Legs 4 PCS	Upper Sliding Doors 2 PCS	Bottom sliding Doors 2 PCS
U 				
Support Leg 1 PC				

HARDWARE LIST

#1  $\varnothing 1/4" \times 1-1/4"$	#2 	#3 	#4  $\varnothing 3\text{mm} \times 5/8"$	#5 
Bolt 22 PCS	Hook 4 PCS	Screw 28 PCS	Flat Head Screw 8 PCS	Shelf Holder 8 PCS
#6  $\varnothing 8 \times 30\text{mm}$	#7  $\varnothing 1/4" \times 11\text{mm}$	#8  $\varnothing 1/4" \times 13\text{mm}$	#9  4mm	#10 
Short Wood Dowel 30 PCS	Spring Washer 22 PCS	Flat Washer 22 PCS	Allen Wrench 1 PC	Safety Strap Kit 1 PC

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.

Please do not use tools to assemble this unit unless specifically indicated.




Reference the images above any time the instructions state "lock the hardware".

Note: Be sure to check all hardware is locked when completed.


Step 1. Attach hooks (part #2) to back upper rail (part F) using flat head screws (part #4) and phillips head screwdriver.

Attach back upper rail (part F) to shelf (part D) using wood dowels (part #6)




#2		x 4
#4		x 8
#6		x 2

Step 2. Lay upper right side panel (part C) on a soft surface such as carpet as shown. Attach assembled unit (parts D & F) and back bottom rail (part G) to upper right side panel (part C) using wood dowels (part #6) and lock the hardware.




#6  x 2

Step 3. Slide middle back panels (part J) and back partition rail (part H) into grooves of assembled unit (Parts D, F & G) as shown.




Step 4. Attach left side panel (part B) to back upper rail (part F), shelf (part D) and bottom rail (part G) using wood dowels (part #6) then lock the hardware.




#6  x 2

Step 5. Attach upper vertical panel (part E) to shelf (part D) using wood dowel (part #6), bolt (part #1), spring washer (part #7), flat washer (part #8) and allen wrench (part #9).




#1  x 1
 #6  x 1
 #7  x 1
 #8  x 1
 #9  x 1

Step 6. Slide upper back panel (part I) into grooves of assembled unit (part B, C, D)



Step 7. Attach top panel (part A) to upper left side panel (part B), upper right side panel (part C), upper vertical panel (part E) and upper back panel (part I) using wood dowel (part #6), bolt (part #1), spring washer (part #7), flat washer (part #8) and allen wrench (part #9).


NOTE: DO NOT FULLY TIGHTEN BOLTS SO THAT TO ASSEMBLE THE SLIDING DOORS !




- | | | |
|----|---|-----|
| #1 |  | x 5 |
| #6 |  | x 3 |
| #7 |  | x 5 |
| #8 |  | x 5 |
| #9 |  | x 1 |

Step 8. Place upper Sliding doors (part S) into the grooves of shelf (Part D) and top panel (part A)


NOTE: FULLY TIGHTEN BOLTS !




Step 9. Attach seat panel (Part K) to upper left side panel (part B), upper right side panel (part C) and back bottom panel (part G) using wood dowel (part #6), bolt (part #1), spring washer (part #7), flat washer (part #8) and allen wrench (part #9).



Step 10. Attach lower left and right side panel (part M & N) and middle vertical panel (part O) to seat panel (part K) using wood dowel (part #6), bolt (part #1), spring washer (part #7), flat washer (part #8) and allen wrench (part #9).




Step 11. Attach bottom panel (part L) to lower left side panel (part M), middle vertical panel (part O) and lower right side panel (part N) using wood dowel (part #6), bolt (part #1), spring washer (part #7), flat washer (part #8) and allen wrench (part #9). NOTE: DO NOT FULLY TIGHTEN BOLTS SO THAT TO ASSEMBLE THE SLIDING DOORS !




Step 12. Place bottom push doors (part T) into the grooves of seat panel (Part K) and bottom panel (part L)

NOTE: FULLY TIGHTEN BOLTS !




Step 13. Attach legs (part R) to bottom panel (part L) using wood dowel (part #6), bolt (part #1), spring washer (part #7), flat washer (part #8) and allen wrench (part #9). Attach support leg (part U) to bottom panel (part L).

Note: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust leveler as needed until it's firmly in contact with the floor in new location.




Step 14. Attach bottom back panel (part Q) to base of assembled unit using screws (part #3) and phillips head screwdriver. fasten back upper rail(part F),back partition rail (part H) and back bottom rail (Part G) to middle back panels (part J) using screws (part #3) and phillips head screwdriver.







#3  x 28

Step 15. Place shelf holders(part #5) into desired position and then slide adjustable shelves (Part P} into place.



#5  x 8

#10	A	B	C	D	E
			 D8*3/4"	 D8*1-1/2"	
Safety Strap Kit 1 PC	Wall Anchor 1 PC	Washer 2 PCS	Short Screw 1 PC	Long Screw 1 PC	Safety Wall Strap 1 PC

SAFETY WALL STRAP INSTALLATION


Note: It is highly recommended to install this safety strap kit to prevent tipping, damage and/or injury.

1. Insert short screw (C) through washer (B) and safety wall strap (E) and attach to back panel (part M) using phillips head screwdriver.

2. Drill a 1 1/32" hole where you want to secure the unit. The drilled hole will be at the same height as the hole in back panel (part M) where the safety wall strap (E) is attached. Tap wall anchor (A) into the hole.

3. Insert long screw (D) through washer (B) and safety wall strap (E) into wall anchor (A) using phillips head screwdriver.

Note: This item is not intended for clothing storage use.



⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



This is a permanent label. Do not remove!