















INSTALLATION MANUAL


KL-YC5656212-6072




PARTS AND HARDWARE LISTING

ITEM	NAME	QTY	PICTURE
①	Sliding Door	1	
②	Glass Panel	1	
③	Top rail	1	
④	Bottom waterproof strip	1	
⑤	Movable glass insert waterproof tape	1	
⑥	Side water baffle strip	2	
⑦	Handle	1	
⑧	WHEEL	2	
⑨	Guide	1	
⑩	Wall seat	2	
⑪	Waterproof tape	1	
⑫	Fixing screws 4mm x 35mm	7	
⑬	Fixing screws 4mm x 25mm	4	
⑭	Hollow wall plugs	11	
⑮	Allen key (2.5mm&3mm&5mm&6mm)	4	


PARTS AND HARDWARE LISTING




REQUIRED TOOLS




1. DRILL




2. DRILL BITS
1/4" & 1/8"




3. SCREWDRIVER




4. LEVEL




5. TAPE MEASURE




6. CUTTING PLIER




7. PENCIL




8. Mallet



9. SILICONE



10. ALLEN KEY
2.5mm&3mm&5mm&6mm







11. SAW

* Use a 1/4" drill bit for ceramic when drilling into ceramic tiles

Overall Installation displaying





Installation effect diagram of shower enclosure













Threshold must be level
Wall must be plumb

NOTE: This model does not
have adjustment for
out-of-plumb conditions





A	L
[60"]	[59 ⁷ / ₁₆ "]









STEP-3-1







STEP-3-2





STEP-3-3







STEP-3-4











STEP-6-1





STEP-6-2





STEP-7-1




STEP-7-2






STEP-7-3



STEP-7-4





STEP-7-5





10



12





STEP-8-1




STEP-8-2





STEP-8-3





STEP-8-4









STEP-9-1




STEP-9-2







STEP-9-3





STEP-9-4














STEP12-1





STEP12-2





STEP12-3





STEP12-4




STEP12-5





STEP12-6





STEP12-7





STEP12-8




STEP12-9




STEP12-10





STEP12-11





Right door




STEP12-1





STEP12-2





STEP12-3





STEP12-4




STEP12-5





STEP12-6





STEP12-7





STEP12-8




STEP12-9






STEP12-10




STEP12-11




STEP13-1





STEP13-2





STEP13-3












STEP-15-1




STEP-15-2




STEP-15-3







STEP-16-1




STEP-16-2




STEP-16-3




STEP-16-4






24 HOURS HEURES



ONLY SEAL THE OUTSIDE OF THE
SHOWER.DO NOT QPLY SILICONE TO
THE IHSIDE OF THE SHOWER

SAFETY INFORMATION



CAUTION

Please carefully read the following important safety information before handling or installing this shower. There is a risk of serious injury while handling this product. To minimize these risks, please note:

- Always wear safety glasses and gloves while handling.
- Always read and follow all the steps in the installation instructions.
- Inspect all contents and glass for damage before installation.
- Extreme caution should be taken while handling the glass during installation as the tempered glass may shatter if in contact with a hard surface.
- Handle the tempered glass with caution! Improperly handling the glass can cause it to break suddenly in small pieces (never in pointed fragments).
- Always take all precautions not to touch the tempered glass with any tools during the installation, or after installed.
- Do not cut or modify the tempered glass as it will shatter if cut.
- Carefully remove product from packaging and keep packaging until installation is complete.
- Inspect all parts for damage; if there is damage to the unit prior to installation, please contact customer service at the number provided in this guide.
- Install the shower on a floor that is level and able to accommodate the weight of the unit and an occupant.
- Consult local building codes and compliance standards prior to installation and ensure conformity.
- After installation, and from time to time, check the glass for fit and finish to ensure that nothing has come loose since installation.
- Keep this installation manual for future reference.




NOTICE

- Any modification or alteration from what is specified in this instruction manual will void any and all warranty on this product.
 - We will not be responsible for any damage to the unit or personal property caused by improper installation.
- If you disregard instructional warnings, you will void your warranty and possibly deal with water damage.

PREPARATION

You will need at least two people to install this unit properly.



Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: Shower (60 min).